
## Model 217, 222



P82.30-3492-79

## Shown model 222.0

A1	Instrument cluster	N69/2	Right front door control unit
B14	Outside temperature sensor	N73	Electronic ignition switch control unit
B38/2	Rain/light sensor with additional functions	N80	Steering column module control unit
B38/2b1	Rain sensor	N127	Drivetrain control unit
K40/6	Driver-side fuse and relay module	R2/4	Lower spray nozzle hose heater (on model 222 with CODE 874 (MAGIC VISION CONTROL, heated), model 217)
M5/1	Windshield washer system pump	R2/5	Upper spray nozzle hose heater (on model 222 with CODE 874 (MAGIC VISION CONTROL, heated), model 217)
M5/2	Night & Day View Assist long-range camera washer fluid pump (with code 610 (Night View Assist))	R2/6	Windshield washer system junction box (on model 222 with CODE 874 (MAGIC VISION CONTROL, heated), model 217)
M6/1	Wiper motor	R2/10	Wiper park heater
N3/9	CDI control unit (with diesel engine, with engine 642 positioned in center, with engine 651 positioned at right)	R2/12	Left wiper blade heater (on model 222 with CODE 874 (MAGIC VISION CONTROL, heated), model 217)
N3/10	ME-SFI [ME] control unit (for gasoline engine, with engine 157, 276.8, 278 located at center, with engine 276.9 located at left, with engine 277, 279 located at right)	R2/13	Right wiper blade heater (on model 222 with CODE 874 (MAGIC VISION CONTROL, heated), model 217)
N10/6	Front SAM control unit	S4	Combination switch
N22/1	Climate control control unit	S62/42	Right engine hood contact switch
N58/1	Climate control operating unit	S62/43	Left engine hood contact switch
N58/1s21	Defrosting button	Y3/8n4	Fully integrated transmission control control unit
N69/1	Left front door control unit		

Component description for instrument cluster	Model 217, 222	GF54.30-P-6000LF
	up to model year 2018 A1	
	Model 217, 222 as of model year 2018 A1	GF54.30-P-6000LFM
Rain/light sensor with additional functions, component description	B38/2	GF54.21-P-6005LF

Component description for CDI control unit	Model 222 with engine 642.8 N3/9	GF07.16-P-6000OGS
	Model 222 with engine 651.9 N3/9	GF07.16-P-6000OLA
Component description for ME-SFI (ME) control unit	Model 222 with engine 276.9 N3/10	GF07.61-P-6000MMK
	Model 217, 222 with engine 157.9, 278.9 N3/10	GF07.61-P-6000MML
	Model 217, 222 with engine 276.8 N3/10	GF07.61-P-6000MMT
	Model 217 with engine 279 Model 222 with engine 277, 279 N3/10	GF07.61-P-6000MUB
Component description for front SAM control unit	N10/6	GF54.21-P-7010LF
Climate control control unit, component description	N22/1	GF83.40-P-2250LF
Front climate control operating unit, component description	N58/1	GF83.40-P-2260LF
Component description for left front door control unit	N69/1	GF72.29-P-6001LF
Component description for right front door control unit	N69/2	GF72.29-P-6009LF
Component description for the electronic ignition lock control unit	N73	GF80.57-P-6001LF
Component description for steering column tube module control unit	Model 217, 222 up to model year 2018 N80	GF54.21-P-6051LF
	Model 217, 222 as of model year 2018 N80	GF54.21-P-6051LFM
Drivetrain control unit, component description	Model 217 with engine 176.9, 177.9 Model 217, 222 (except 222.163/173) with engine 157.9, 276.8, 277, 278.9, 279 Model 222 with engine 176.9, 177.9, 256.9 N127	GF54.21-P-2141LF
	Model 222 with engine 276.9 Model 222.163 with engine 276.8 N127	GF54.21-P-2141MMk
	Model 222 with engine 642.8 N127	GF54.21-P-21410GS
	Model 222 with engine 651.9 N127	GF54.21-P-2141OLA
Component description for fully integrated transmission control unit	Model 222 with transmission 724.2 up to model year 2018 Y38n4	GF27.60-P-5165LFH
	Model 217, 222 with transmission 722.9 (except 722.931/932/971) Y38n4	GF27.60-P-5165AHB
	Model 217, 222 with transmission 722.931/971 Y38n4	GF27.60-P-5165AHD
	Model 217, 222 with transmission 722.932 Y38n4	GF27.60-P-5165AHY