


Fuse and relay box in right of engine compartment

28-49 Fuses
 K40/7 Right front fuse and relay module

K-P relay

X Direction of travel



P54.15-2032-05

Bay	Designation
K	Motor electronics/chassis relay (K40/7kK)
L	Starter relay (K40/7kl)
M	Only valid for diesel: CDI relay (K40/7kM)
N	Air pump relay (K40/7kN)
O	Air compressor relay (K40/7kO)
P	Fanfare horns relay (K40/7kP)