

Assignment of fuse box

⊙ A 129 545 22 00 SB 01.04.98

Consumer	Fuse-no.	Consumer	Fuse-no.	Consumer	Fuse-no.	Consumer	Fuse-no.
38-pin diagnosis	37	Cruise control	10	Left low beam	6	Seat occupied recognition	22
ADS	14, 23, 37	Daytime running lamps	2, 3, 18	Left side lamp	3	Secondary air injection clutch	37
Air conditioning	15, 17, 33	Dimming interior mirror	18	Left trailer taillamp	3	Sidebag sensors	22
Air pump	M4	Dome lamp	10, 14	Licence plate lamp	2	Soft top	20
Airbag	22	Electronic Stability Program	37	Mirror/steering column adjustment	21	Stationary heater timer	31, 32
Airbag indicator	13	Exit lamps	14	OBD II	37	Stop lamps	10
Amplifier	24	Exterior mirror	18	Radio	13, 24	Sun blind	21
Ashtray lamp	2	Foglamps	5	Rain sensor	13	Tele-Aid	12
ATA system	20	Folding exterior mirrors	13	Rear foglamp	5	Telephone	12, 16
Auto-Pilot System	12, 23	Hazard warning flashers	14	Rear window defroster	14, M1	Trailer coupling	13
Autom. trans. - gear recognition	11	Headlamp cleaning system	2	Reverse lamp	11	Trailer coupling stop lamp	10
Auxiliary fan control unit	M3	Headlamp flasher	12	Right backrest lock	20	Trailer rear foglamp	5
Blower control (Air conditioning)	M2	Headlamp range control	1, 10	Right high beam, high-beam indicator	9	Trip computer	14, 16
Bulb failure monitor unit	18	Heated seats	13, 25	Right low beam	7	Turn signal lamp control	12
Central locking	4, 15, 20	Horn	11	Right side lamp	2	Vanity mirror illumination	14
Cigar lighter	13	Ignition coils	34	Right trailer taillamp	2	Washer fluid heater	18
Clock	14	Instrument cluster	10, 13, 16	Roll-over bar	19	Wiper control	12
Combination relay	14, M1	Left backrest lock	19	Seat adjustment	21, 26, 27	Wiper motor	M1
Convenience relay	13, 23	Left high beam	8	Seat belt reminder lamp	2		

Fuse-no.	Rating	Color	Fuse-no.	Rating	Color
1,3,4,8,9,16,17,19,20,22,31,33	7,5A	brown	24, 25, 26, 27	25A	natural
15, 37	10A	red	30, 35, 36	---	---
5, 6, 7, 10, 12, 18, 23, 34	15A	blue	M1, M2 (MAXI)	30A	green
13, 14, 21, 32	20A	yellow	M3, M4 (MAXI)	40A	orange

Note:

- Fuse extractor in car tool kit.
- Observe correct amperage!
- Additional fuses in trunk.
- In the event of any faults in the audio or communication systems, please observe the instructions in the Owner`s Manual.