



Side panelling above battery

Battery

Mounting nuts (2) on rear centerpiece

Side panelling on left (below taillight)

Washers for nuts (2)

Bumper

remove.

disconnect, screw out and remove.

screw off.

swing out until washers are accessible.

remove (use rod magnet for center washer)

pull out toward rear.



If the mount (3) is bent:

Cover on side panelling on left

Nuts (1)

Mount (3)

Install in reverse order.

remove.

screw off.

remove.

**Note**

Install seal for bulkhead (rear wheel house) below front part of bumper.