


AR82.70-P-0003R	Remove/install voice control system control unit	1.2.06
-----------------	--	--------

**MODEL 230.4 with CODE (813) Voice control system (VCS [SBS])**






P82.70-6152-09

- 1 Stowage box
- 2 Cover
- 3 Bolts
- 4 Cover

- 5 Bolts
- 6 Plug connections
- 7 Control unit bracket
- 8 Retaining clamp

A35/11 Voice control system control unit

	<p><b>Remove/install</b></p>		
<p>1</p>	<p>Switch off the ignition and remove the transmitter key from the EIS control unit</p>	<p> On vehicles with code (889) Keyless Go, press the Keyless Go</p>	

		start/stop button repeatedly until the ignition is switched off. Remove the Keyless Go transmitter card or transmitter key from the vehicle and store beyond the reach of the transmitter (min. 2 m).	
2	Open cover (2) of stowage box (1)		
3	Remove bolts (3)		
4	Close cover (2) of stowage box (1)		
5	Take off cover (4)	 <b>Installation:</b> Ensure retaining clamps (8) in the control unit bracket (7) are seated correctly.	
6	Remove bolts (5)		
7	Disconnect connectors (6) from voice control system control unit (A35/11)	 To avoid damaging them, do not kink fiber optic cables, route over sharp edges or bend in radii smaller than 25 mm.	
		 Cover fiber optic cable coupling and implement connection on voice control system control unit (A35/11). Refer to:↓	
		Cover fiber optic cable	<a href="#">AR82.95-P-0005-01A</a>
8	Push voice control system control unit (A35/11) to the rear and remove from control unit bracket (7)		
9	Install in the reverse order		