


ENGINE 112, 113, 120, 137, 271, 272, 273, 275, 285, 628, 629, 642, 651



P01.10-2660-08

Shown on engine 275

i The engine number is located on the upper right transmission flange

i On OM 642 the engine number is located at the front left on the cylinder crankcase below the high-pressure pump

i On OM 651 the engine number is located on the left side on the cylinder crankcase below the vacuum pump