


K40/2 Driver-side fuse and relay module

X Direction of travel



P54.15-2316-05

| Position | Designation |
|----------|---|
| A | ● Wiper park heater relay (K40/2kA) |
| B | ● Terminal 15 relay (K40/2kB) |
| C | ● Terminal 15R relay (K40/2kC) |
| D | ● Relay 1, steering column tube longitudinal adjustment (K40/2kD) |
| E | ● Relay 2, steering column tube longitudinal adjustment (K40/2kE) |
| F | - |
| G | ● Wiper stage 1 and 2 relay (K40/2kG) |
| H | ● Wiper On and Off relay (K40/2kH) |
| I | ● Steering column height adjustment relay 1 (K40/2kI) |
| J | ● Steering column height adjustment relay 2 (K40/2kJ) |