


Model 231



P54.15-3450-09

Shown on model 231

F34 Vehicle interior fuse box
 N10/1 Front SAM control unit with fuse and relay module

N10/2 Rear SAM control unit with fuse and relay module

Shown on model 231

F32 Front electrical prefuse box



P54.15-3911-06

	Fuse assignment of front prefuse box	Model 231 as of model year 2017 F32	GF54.15-P-1256-07RKM
--	--------------------------------------	---	----------------------

		Model 231 up to model year 2017 F32	GF54.15-P-1256-07RK
	Fuse assignment of fuse box in left of cockpit	Model 231 as of model year 2017 F34 Model 231 up to model year 2017 F34	GF54.15-P-1256-13RKM GF54.15-P-1256-13RK
	Fuse assignment of fuse and relay box in right engine compartment	Model 231 as of model year 2017 N10/1 Model 231 up to model year 2017 N10/1	GF54.15-P-1256-02RKM GF54.15-P-1256-02RK
	Relay assignment of fuse and relay box in right engine compartment	N10/1	GF54.15-P-1257-02RK
	Fuse assignment of rear fuse and relay box	Model 231 as of model year 2017 N10/2 Model 231 up to model year 2017 N10/2	GF54.15-P-1256-01RKM GF54.15-P-1256-01RK
	Relay assignment of rear fuse and relay box	Model 231 as of model year 2017 N10/2 Model 231 up to model year 2017 N10/2	GF54.15-P-1257-01RKM GF54.15-P-1257-01RK