
GF54.15-P-1257-02RK	Relay assignment of fuse and relay box in	
	right engine compartment	

MODEL 231



P54.15-3380-09

N10/1 Front SAM control unit with fuse and relay module

X Direction of travel

Relay	Designation	
J	Circuit 15 relay (N10/1kJ)	
K	Circuit 15R relay (N10/1kK)	
L	Wiper park position heater relay (N10/1kL)	
M	Starter circuit 50 relay (N10/1kM)	
N	Engine circuit 87 relay (N10/1kN)	
0	Horn relay (N10/1kO)	
Р	 Secondary air injection relay (N10/1kP) 	
Q	Spare relay (N10/1kQ)	
R	Chassis circuit 87 relay (N10/1kR)	