

Document number: pe54.21-p-2108-97rka

Document title: Wiring diagram / rear SAM control unit with fuse and relay module (N10/2)

Code:	Designation:	Position:
A0	Color code key	56L
B95	Battery sensor	50L
Code 220	PARKTRONIC	38H
Code 235	Active Park Assist	38H
E18/4	Right luggage compartment lamp	26L
E18/5	Left luggage compartment lamp	24L
E19/1	Left license plate lamp	31L
E19/2	Right license plate lamp	30L
E21	Center stop lamp	28L
E3	Left rear lamp unit	16L
E3/7	Center rear lamp unit	36L
E3e1	Left rear turn signal lamp	15L
E3e10	Upper left brake light and taillight	17L
E3e4	Left stop lamp	15L
E3e6	Left rear side marker lamp	15L
E3e9	Lower left brake light and taillight	16L
E4	Right rear lamp unit	19L
E40/2	Left trunk lid ambient lamp and warning lamp	33L
E4e1	Right rear turn signal lamp	18L
E4e10	Upper right brake light and taillight	20L
E4e4	Right stop lamp	18L
E4e6	Right rear side-marker lamp	19L
E4e9	Lower right brake light and taillight	20L
F32	Front electrical prefuse box	46L
F32	Front electrical prefuse box	3L
F32f153	Prefuse 153	1K
F32f158	Prefuse 158	3K
N10/2	Rear SAM control unit with fuse and relay module	4A
N10/2	Rear SAM control unit with fuse and relay module	12A
N10/2	Rear SAM control unit with fuse and relay module	20A
N10/2	Rear SAM control unit with fuse and relay module	28A
N10/2	Rear SAM control unit with fuse and relay module	36A
N10/2	Rear SAM control unit with fuse and relay module	44A
N10/2	Rear SAM control unit with fuse and relay module	52A
U1	Valid for USA	41F
U2	Valid for all except USA	40F
U2	Valid for all except USA	41F
U2006	Valid up to model year 2014/2	23G
U2006	Valid up to model year 2014/2	51F
U2007	Valid as of model year 2014/2	23H
U2007	Valid as of model year 2014/2	51F
U340	Valid without code 235 Active Park Assist	41H
U380	Valid without code 220 PARKTRONIC	41H
W6/1	Left taillamp trunk ground point	25F
W6/1	Left taillamp trunk ground point	42F
W7/1	Right taillamp trunk ground point	27F
W7/1	Right taillamp trunk ground point	33F
W71/2	Right rear compartment ground point	17F
W71/2	Right rear compartment ground point	31F
W71/2	Right rear compartment ground point	4G
W71/2	Right rear compartment ground point	42F
X30/33	Interior CAN 2 (CAN B) potential distributor electrical connector	53L
X35/28	Rear bumper parking system electrical connector	39J
X8/11	Center rear seat lamp unit electrical connector	41J
X8/43	Right trunk lid electrical connector	28H
Z6/92z1	Trunk lid ground connector sleeve	34H

