


MODEL 231

with CODE 409 (Left/right front multicontour seat)

with CODE 432 (Active multicontour seat)




P91.60-4517-09

Shown on left front seat

- 8 Screw
- 9 Screw

- 10 Back shell
- 11 Backrest frame

- 12 Pneumatic line
- 13 Electrical connector
- 14 Catch hook
- 15 Bracket
- N32/19 Driver-side active multicontour seat control unit
- N32/22 Passenger-side active multicontour seat control unit



P91.25-2597-06



Remove/install

1	Remove seat-back lining from front seat backrest		AR91.10-P-1910RK
2	Remove bolts (8)		
3	Remove screw/bolts (9)		
4	Carefully pull back shell (10) at bottom slightly forward (arrow A) out of backrest frame (11) until driver-side active multicontour seat control unit (N32/19) or passenger-side active multicontour seat control unit (N32/22) is accessible		
5	Disconnect pneumatic lines (12) at driver-side active multicontour seat control unit (N32/19) or passenger-side active multicontour seat control unit (N32/22)	i Installation: Ensure correct color assignment and seating of pneumatic lines (12) at driver-side active multicontour seat control unit (N32/19) or passenger-side active multicontour seat control unit (N32/22).	
6	Disconnect electrical connections (13)		
7	Release catch hook (14) and remove driver-side active multicontour seat control unit (N32/19) or passenger-side active multicontour seat control unit (N32/22) upwards out of bracket (15)	i Installation: Ensure correct seat of driver-side active multicontour seat control unit (N32/19) or passenger-side active multicontour seat control unit (N32/22) in bracket (15).	
8	Install in the reverse order		