

# **Contents**

Models 203 and 209 (C-Class and CLK-Class)	3
Models 204 andX204 (C-Class and GLK-Class)	4
	5
Model 211 as of 09/01/2003 (E-Class)	6
Model 219 (CLS-Class)	
Model 230 up to MY2007 (SL-Class)	10
Model 230 (SL-Class from MY2008 to Present)	11
Models 164, X164 and 251 (M-Class, GL-Class, and R-Class)	12



## Models 203 and 209 (C-Class and CLK-Class)





- 1. Insert key into ignition, switch to position "1".
- 2. Press buttons or repeatedly until the mileage is displayed within the Multifunction display.
- 3. Press cluster illumination button (1) 3 times in short succession. The battery voltage will be displayed and an audible signal will sound.
- 4. Turn key in ignition to position "2"
- 5. Press the up 4 buttons until the service menu appears.
- 6. Press cluster illumination button (1) once. The Oil Type menu is displayed.
- 7. Use the + and buttons to select the oil used for the service.
- 8. Press the up / buttons to confirm. The display will show: "Reset Oil Confirmation. Push R-Button for 3 seconds".
- 9. Press and hold the cluster illumination button (1) for 3 seconds. The message "Service confirmed" is displayed.

## Models 204 and X204 (C-Class and GLK-Class)



- 1. Insert key into ignition, switch to position "1". The mileage counter has to be displayed.
- 2. Press repeatedly until the TRIP option is highlighted.
- 3. Press and hold and within 1 second press OK and hold both for 5 seconds. The shop menu is displayed.
- 4. Press repeatedly until "Assyst Plus" is highlighted and confirm with OK.

  Options "Service Data" and "Full Service" are displayed.
- 5. Press until "Full Service" is highlighted. Confirm with OK.
- 6. Press until "Conf. Full Serv." is highlighted, confirm with OK. The display shows "Service carried out?."
- 7. Press to select "Yes". Confirm with OK. "Cannot be undone" displays.
- 8. Press until "Confirm" is highlighted. Confirm by pressing OK. The display reads "Full Service carried out".
- 9. Confirm by pressing OK

## Model 211 Up to 8/31/2003 (E-Class)



- 1. Turn key in ignition swith to position "2."
- 2. Use buttons until the "Service" menu is shown in the Multifunction Display.
- 3. Press and hold Reset Button R (1) until the Service Menu is displayed.
- 4. Use buttons + and to highlight option "Confirm"
- 5. Press buttons or to confirm.

## Model 211 as of 09/01/2003 (E-Class)





- 1. Insert key into ignition, switch to position "1".
- 2. Press buttons or repeatedly until the mileage is displayed within the Multifunction display.
- 3. Press cluster illumination button (1) 3 times in short succession. The battery voltage will be displayed
- 4. Press the up 4 buttons until the service menu appears.
- 5. Use the and buttons to select menu option "Confirm".
- 6. Press until "Complete Service" is selected.
- 7. Confirm "Complete Service" with button . The display will show "Service Confirmed".

## Model 219 (CLS-Class)



- 1. Insert key into ignition, switch to position "1".
- 2. Press buttons or repeatedly until the mileage displays within the Multifunction display.
- 3. Press reset button (1) 3 times in short succession. The battery voltage will be displayed
- 4. Press the up 4 buttons until the service menu appears.
- 5. Use the hand buttons to select menu option "Confirm".
- 6. Press button until "Complete Service" is selected.
- 7. Confirm "Complete Service" with button . The display will show "Service Confirmed".

## Models 221 and 216 (S-Class and CL-Class)



- 1. Insert key into ignition, switch to position "1". The mileage counter has to be displayed.
- 2. Press and hold and within 1 second press OK and hold both for 5 seconds. The shop menu is displayed.
- 3. Press repeatedly until "Assyst Plus" is highlighted and confirm with OK.
- 4. Press until "Service carried out" is highlighted. Confirm with OK.
- 5. Press to select "Service due". Confirm with OK.
- 6. Press to select "Full Service". Confirm with OK.

## Model 171 (SLK-Class)



- 1. Insert key into ignition, switch to position "1".
- 2. Press buttons or repeatedly until the mileage is displayed within the Multifunction display.
- 3. Press cluster illumination button (1) 3 times in short succession. The battery voltage will be displayed
- 4. Press the up 🗘 / 🕏 buttons until the service menu appears.
- 5. Use the and buttons to select menu option "Confirm".
- 6. Press until "Complete Service" is selected.
- 7. Confirm "Complete Service" with . The display will show "Service Confirmed".

# Model 230 up to MY2007 (SL-Class)



- 1. Insert key into ignition and switch to position "1"
- 2. Press button or until the main mileage display is shown.
- 3. Press reset button R (1) and hold for 3 seconds.
- 4. The message "DO YOU WANT TO RESET THE SERVICE INTERVAL? "CONFIRM WITH R BUTTON" displays.
- 5. Press button R (1) again.
- 6. Switch off ignition and remove the key.

## Model 230 (SL-Class from MY2008 to Present)



- 1. Switch ignition to position "2"
- 2. Press button or until the main mileage display is shown.
- 3. Press button oir until the service menu appears in the left display.
- 4. Press button R (1) for approximately 5 seconds. The message "Service interval... Reset: Press reset button for 3 seconds" appears.
- 5. Press and hold button R (1) for approximately 3 seconds to confirm.
- 6. Switch off ignition and remove key.

### Models 164, X164 and 251 (M-Class, GL-Class, and R-Class)





### **Reset Service Indicator**

- 1. Insert key into ignition, switch to position "1".
- 2. Press buttons or repeatedly until the mileage is displayed within the Multifunction display.
- 3. Press cluster illumination button (1) 3 times in short succession. The battery voltage will be displayed
- 4. Press the up 4 / buttons until the service menu appears.
- 5. Use the + and buttons to select menu option "Confirm".
- 6. Press button until "Complete Service" is selected.
- 7. Confirm "Complete Service" with button Let . The display will show "Service Confirmed".

Feedback welcome on startekinfo.team@mbusa.com.