Stealth License Plate

Remote Version Instruction Manual



PLEASE CAREFULLY READ THE DISCLAIMER PRECAUTION

SECTION BELOW BEFORE INSTALLING OR USING YOUR

STEALTH LICENSE PLATE SYSTEM. THE SECTION BELOW

CONTAINS IMPORTANT INFORMATION.



WARNING - Legal Implications

Stealth License Plate is to be used strictly for show and photography purposes. We do not commend any illegal behavior while using this product. Before installing this product, check your applicable local/state laws and regulations.



WARNING - Installation Procedures

Before installing, be sure to completely read the installation instructions. We assume no liability for any damage done to your car or Stealth License Plate from installation errors. If you do not feel comfortable installing it, please go to a professional.

Installation Instructions

- 1. Use screws that fit your specific car to fix the frames on both the front and/or rear license plate.
- 2.Pull the connector cables from the left or right hidden cable channels into the interior of the car.
- 3.Put the control box in a desirable location (ie. Under glove box.)
 - 4. Then plug the power cord into the cigarette lighter plug.
- 5.If something is blocking the opening or closing of the shield, the indicator light flashes immediately. If this occurs, please check the mounting area.
 - 6.After completing 1-5, continue on to "How to use Stealth Plate."

How to use Stealth Plate

Indicator light in cab:

You can see here whether the outside license plate is covered or not.

- 1. Both frames are covered, both lights turn blue.
- 2.Only front frame is covered, light A turns blue.
- 3.Only back frame is covered, light B turns blue.



How to use Stealth Plate...

Remote control procedures:

Note: Plug the control module into the cigarette lighter and power on. Once powered on, follow the next steps from either the control module or the remote control:

Function 1: Press button A, the front plate cover closes to hide license plate. Press A again to uncover plate.



Function 2: Press button B, the rear plate cover closes to hide license plate. Press B again to uncover plate.



Function 3: Press button C, front and rear plate cover closes to hide both license plates simultaneously. Press C again to uncover both plates simultaneously.

Stealth Plate Characteristics

- 1. Anti-concealed camera
- 2. Safeguarding the personal privacy
- 3. Same as the common car license plate frame, sleek appearance and covert at the same time
- 4. Rust resistant material, stable quality, for long term use.
- 5. Fast moving, just needs 1.5 seconds, can meet your urgent needs
- 6. The license frame was made by high quality materials for years of trouble free use. The cushion used is an aging-prevented army grade canvas; it can completely endure the sunshine, rain, frost and any high-low temperature or worse environments.

Stealth Plate Specifications

- 1. Entering voltage: DC 12V
- 2. Fixed electric current: 0.6A
 - 3. Fixed power: 2W
- 4. Ascend and descend time: 1.5 seconds
- 5. Control distance: Approximately 50M

6. Weight: 2.52 Kg

7.Product Size 31.5cm(L)×17cm(H)

