Engine 152, 157, 278

Nm Oil filter

Number	Designation			Engine 152	Engine 157
BA18.20-P-1002-01Z	Screw plug to oil filter housing	M12	Nm	20	20

Nm Oil filter

Number	Designation				Engine 152	Engine 157
BA18.20-P-1003-01Z	Bolt, oil filter housing to timing case cover	M7	Stage 1	Nm	5	5
			Stage 2	Nm	14	14
		M8	Stage 1	Nm	5	5
			Stage 2	Nm	20	20

Nm Oil filter


Number	Designation				Engine 278	
BA18.20-P-1005-01Y	Screw plug to oil filter housing		M12		Nm	20

Nm Oil filter

Number	Designation				Engine 278
BA18.20-P-1006-01Y	Bolt, oil filter housing to timing case cover	M7	Stage 1	Nm	5
			Stage 2	Nm	14
		M8	Stage 1	Nm	5
			Stage 2	Nm	20

Tightening sequence

- Bring the oil filter housing (18) into the installation position and position screws (21 to 27), successively, as per the 1 numerical sequence, in ascending order.
- Tighten screws (21 to 27) successively, as per numerical sequence, in ascending order. Engine 278 Engine 152 2 Engine 157 Mm
- Tighten screw plug (20). Engine 278 3 Engine 152 Engine 157 Mm
- Oil filter housing 18
- 20 Screw plug
- 21 Screw
- 22 Screw Screw
- 23 24
- Screw 25 Screw
- 26
- Screw



P18.20-2105-11

@ Daimler AG, 5/5/21, L/07/19, ar18.20-p-3471-01mmb, Bolt plan for oil filter housing Engine 152, 157, 278

27 Screw