

## MODEL all

	Hydraulic pump	Model 166 with engine 157, 276, 278, 642 Model 292 with engine 157, 276, 278, 642	BA32.00-P-1000-01A
	Hydraulic pump	MODEL 231 with ENGINE 157, 276, 278, 279	BA32.00-P-1000-01B
	Hydraulic pump	Engine 157, 176, 278 in model 217 Engine 157, 176, 278 in model 222 Engine 176 in model 223	BA32.00-P-1000-01C
	Hydraulic pump	Model 217, 223 with engine 279 Model 222 with engine 277, 279	BA32.00-P-1000-01D
	Front axle steel springs	MODEL 163	BA32.20-P-1000-01A
	Front axle torsion bar	MODEL 129	BA32.20-P-1000-02A
	Front axle torsion bar	MODEL 140, 171, 172, 203, 209, 211	BA32.20-P-1000-02B
	Front axle torsion bar	MODEL 170, 202, 208	BA32.20-P-1000-02C
	Front axle torsion bar	MODEL 210 ...	BA32.20-P-1000-02D
	Front axle torsion bar	MODEL 210 ...	BA32.20-P-1000-02E
	Front axle torsion bar	MODEL 168, 414	BA32.20-P-1000-02F
	Front axle torsion bar	MODEL 163	BA32.20-P-1000-02G
	Front axle torsion bar	Model 190, 197, 199, 220, 230, 231	BA32.20-P-1000-02H
	Front axle torsion bar	MODEL 240	BA32.20-P-1000-02J
	Front axle torsion bar	MODEL 117, 156, 169, 176, 242, 245 (except 245.286), 246	BA32.20-P-1000-02K
	Front axle torsion bar	MODEL 164.1/8, 251	BA32.20-P-1000-02L
	Front axle torsion bar	MODEL 219.3	BA32.20-P-1000-02M
	Front axle torsion bar	Model 216, 217, 221, 222, 223	BA32.20-P-1000-02O
	Front axle torsion bar	MODEL 204, 207, 212, 218	BA32.20-P-1000-02P
	Front axle torsion bar	Model 166, 292	BA32.20-P-1000-02Q
	Front axle torsion bar	Model 205, 206, 213, 238	BA32.20-P-1000-02R
	Front axle torsion bar	Model 253	BA32.20-P-1000-02T
	Rear axle steel suspension	MODEL 129	BA32.20-P-1000-03A
	Rear axle torsion bar	MODEL 129	BA32.20-P-1000-04A
	Rear axle torsion bar	MODEL 140	BA32.20-P-1000-04B
	Rear axle torsion bar	MODEL 170, 171, 172, 202, 203, 208, 209	BA32.20-P-1000-04C
	Rear axle torsion bar	MODEL 210	BA32.20-P-1000-04D
	Rear axle torsion bar	MODEL WDB168.032 MODEL 9BM168.032, 168.006/007/008/009/031/033/035/109/131/132/133/135, 414.700	BA32.20-P-1000-04E
	Rear axle torsion bar	MODEL 163	BA32.20-P-1000-04F
	Rear axle torsion bar	MODEL 211, 216, 220, 221, 230, 231	BA32.20-P-1000-04G
	Rear axle torsion bar	MODEL 240	BA32.20-P-1000-04I
	Rear axle torsion bar	MODEL 219	BA32.20-P-1000-04J
	Rear axle torsion bar	MODEL 169, 245 (except 245.286)	BA32.20-P-1000-04K
	Rear axle torsion bar	MODEL 164.1/8	BA32.20-P-1000-04L
	Rear axle torsion bar	MODEL 251	BA32.20-P-1000-04M
	Rear axle torsion bar	MODEL 204, 207, 212, 218	BA32.20-P-1000-04N
	Rear axle torsion bar	Model 190, 197	BA32.20-P-1000-04O
	Rear axle torsion bar	Model 166, 292	BA32.20-P-1000-04P
	Rear axle torsion bar	MODEL 117, 156, 176, 242, 246	BA32.20-P-1000-04Q
	Rear axle torsion bar	MODEL 217, 222	BA32.20-P-1000-04R
	Rear axle torsion bar	Model 205, 206, 213, 238	BA32.20-P-1000-04S
	Rear axle torsion bar	Model 253	BA32.20-P-1000-04T
	Rear axle torsion bar	Model 223	BA32.20-P-1000-04V
	Air suspension	Model 211, 219 with code 489 (AIRMATIC) Model 211 except code 489 (AIRMATIC) Model 220, 240	BA32.22-P-1000-03A
	Air suspension	Model 164.1/8 with code 489 (AIRMATIC) Model 166 Model 167 Model 292	BA32.22-P-1000-03B
	Air suspension	Model 251	BA32.22-P-1000-03C
	Air suspension	MODEL 216, 221	BA32.22-P-1000-03D
	Air suspension	MODEL 212, 218	BA32.22-P-1000-03E
	Air suspension	Model 217, 222, 223	BA32.22-P-1000-03F
	Air suspension	Model 205, 253, 293	BA32.22-P-1000-03G
	Air suspension	Model 213, 238	BA32.22-P-1000-03H

	Air suspension	Model 257	BA32.22-P-1000-03I
	Air suspension	Model 290	BA32.22-P-1000-03J
	Front axle shock absorber	MODEL 140	BA32.25-P-1000-01A
	Front axle shock absorber	MODEL 170, 171, 202, 203, 208, 210	BA32.25-P-1000-01B
	Front axle shock absorber	MODEL 163	BA32.25-P-1000-01C
	Front axle shock absorber	MODEL 209	BA32.25-P-1000-01E
	Front axle shock absorber	MODEL 219.3	BA32.25-P-1000-01F
	Front axle shock absorber	MODEL 164.1/8	BA32.25-P-1000-01G
	Front axle shock absorber	MODEL 251	BA32.25-P-1000-01H
	Front axle shock absorber	MODEL 172	BA32.25-P-1000-01N
	Front axle shock absorber	Model 166, 167, 292	BA32.25-P-1000-01O
	Front axle damper strut	MODEL 129	BA32.25-P-1000-02A
	Rear axle shock absorber	MODEL 129, 170, 171, 172, 202, 203, 208, 209	BA32.25-P-1000-03A
	Rear axle shock absorber	MODEL 140, 210	BA32.25-P-1000-03B
	Rear axle shock absorber	MODEL 9BM168.032 MODEL WDB168.032, 168.006/007/008/009/031/033/035/109/131/132/133/135, 414	BA32.25-P-1000-03C
	Rear axle shock absorber	MODEL 163	BA32.25-P-1000-03D
	Rear axle shock absorber	MODEL 211.0 with CODE 489 (Airmatic (semi-active air suspension)) MODEL 211.2/6	BA32.25-P-1000-03G
	Rear axle shock absorber	MODEL 219	BA32.25-P-1000-03I
	Rear axle shock absorber	MODEL 117, 156, 169, 176, 242, 245 (except 245.286), 246	BA32.25-P-1000-03J
	Rear axle shock absorber	Model 164.1/8, 166, 167, 292	BA32.25-P-1000-03K
	Rear axle shock absorber	MODEL 251	BA32.25-P-1000-03L
	Rear axle shock absorber	MODEL 204, 207, 212, 218	BA32.25-P-1000-03M
	Rear axle shock absorber	Model 205, 206, 213, 238, 253, 257, 290, 293	BA32.25-P-1000-03P
	Rear axle shock absorber	Model 118, 177, 243, 247	BA32.25-P-1000-03R
	Spring struts	MODEL 168.006/007/008/009/031/032/033/035/109/131/132/133/135, 414.700	BA32.25-P-1000-04A
	Spring struts	MODEL 211, 215, 220, 230 ...	BA32.25-P-1000-04B
	Spring struts	MODEL 220 ...	BA32.25-P-1000-04C
	Spring struts	MODEL 240	BA32.25-P-1000-04G
	Spring struts	Model 190, 197, 199	BA32.25-P-1000-04H
	Spring struts	Model 117, 118, 156, 169, 176, 177, 242, 243, 245, 246, 247	BA32.25-P-1000-04J
	Spring struts	MODEL 219	BA32.25-P-1000-04K
	Spring struts	MODEL 216, 221	BA32.25-P-1000-04L
	Spring struts	MODEL 204, 207, 212, 218	BA32.25-P-1000-04M
	Spring struts	MODEL 231	BA32.25-P-1000-04N
	Spring struts	Model 217, 222, 223	BA32.25-P-1000-04O
	Spring struts	Model 205, 206, 213, 238, 253, 257, 290, 293	BA32.25-P-1000-04P
	Rear axle spring strut	MODEL 140, 210 ...	BA32.30-P-1000-01A
	Rear axle spring strut	MODEL 202, 203.2, 208 with CODE 480 (Rear axle level control system)	BA32.30-P-1000-01B
	Rear axle spring actuator	MODEL 140, 202, 203, 208, 210 ...	BA32.30-P-1000-02A
	Rear axle level controller	MODEL 129, 140, 202, 203, 208, 210 ...	BA32.30-P-1000-03A
	Distributor fitting	MODEL 129 with CODE 216 (Adaptive damping system (ADS II) with electronic level control)	BA32.31-P-1000-01A
	Suspension strut, front axle level control	MODEL 129 ...	BA32.31-P-1000-02A
	Rear axle level control spring strut	MODEL 129 ...	BA32.31-P-1000-03A
	Front axle level control spring actuator	MODEL 129 with CODE 216 (Adaptive damping system (ADS II) with electronic level control)	BA32.31-P-1000-04A
	Rear axle level control spring actuator	MODEL 129 with CODE 216 (Adaptive damping system (ADS II) with electronic level control)	BA32.31-P-1000-05A
	Level control valve unit	MODEL 129 with CODE 216 (Adaptive damping system (ADS II) with electronic level control)	BA32.31-P-1000-06A
	Rear axle level control damper valve	MODEL 129 with CODE 216 (Adaptive damping system (ADS II) with electronic level control)	BA32.31-P-1000-07A
	Front axle level control damper valve	MODEL 129 with CODE 216 (Adaptive damping system (ADS II) with electronic level control)	BA32.31-P-1000-08A
	Front axle spring strut pressure oil lines	MODEL 129 ...	BA32.31-P-1000-09A
	Front axle ADS shock absorber	MODEL 140 as of 6/1/94, 210 with CODE 217 (Level control on rear axle with ADS)	BA32.32-P-1000-01A
	Rear axle damper valve	MODEL 140 as of 6/1/94, 210 with CODE 217 (Level control on rear axle with ADS)	BA32.32-P-1000-02A
	Active roll stabilization	Model 166, 292	BA32.34-P-1000-01A
	Stabilizer	MODEL 164.1/8	BA32.35-P-1000-01B

	Stabilizer	MODEL 251	BA32.35-P-1000-01C
	Stabilizer	MODEL 169 with ENGINE 780	BA32.35-P-1000-01E
	Front axle stabilizer bar	Model 118, 177, 243, 247	BA32.35-P-1000-02A
	Front axle stabilizer bar	Model 257, 290, 293	BA32.35-P-1000-02B
	Front axle stabilizer bar	Model 190	BA32.35-P-1000-02C
	Front axle stabilizer bar	Model 167	BA32.35-P-1000-02D
	Rear axle stabilizer bar	Model 118, 177, 243, 247	BA32.35-P-1000-03A
	Rear axle stabilizer bar	Model 257	BA32.35-P-1000-03B
	Rear axle stabilizer bar	Model 290	BA32.35-P-1000-03C
	Rear axle stabilizer bar	Model 190, 197	BA32.35-P-1000-03D
	Rear axle stabilizer bar	Model 167	BA32.35-P-1000-03E
	Rear axle stabilizer bar	Model 293	BA32.35-P-1000-03F
	Active Body Control suspension	MODEL 215, 220, 230 with CODE 487 (Active Body Control (ABC))	BA32.50-P-1000-01A
	Active Body Control suspension	MODEL 216 MODEL 221 with CODE 487 (Active Body Control (ABC))	BA32.50-P-1000-01B
	Active Body Control suspension	MODEL 231	BA32.50-P-1000-01C
	Active Body Control, lines	MODEL WDB230.475 2F, 230.476/479 with CODE 487 (Active Body Control (ABC))	BA32.50-P-1000-02A
	Active Body Control, lines	MODEL 215, 216, 220, 221, 230, 231 ...	BA32.50-P-1000-02B
	Active Body Control	MODEL 230	BA32.50-P-1000-03A
	Active Body Control	MODEL 217, 222	BA32.50-P-1000-03B
	Electrohydraulic suspension	Model 167	BA32.50-P-1000-04A
	Electrohydraulic suspension	Model 223 with code 490 (Electrohydraulic suspension)	BA32.50-P-1000-04B