



P54.21-2189-09

- 1 Floor mat
2 Vapor barrier
3 Footrest

- 4 Nut
5 Electrical connectors
6 Bolt

N10/11 Passenger-side SAM control unit

Modification notes

12.4.05	Disconnect ground cable of battery deleted	Step 2	
---------	--	--------	--

	Remove/Install		
	Notes on avoiding damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1.1	Connect STAR DIAGNOSIS and cache the base data from the SAM control unit (front passenger side) (N10/11) in STAR DIAGNOSIS	When installing new passenger-side SAM control unit (N10/11).	
	Connect STAR DIAGNOSIS and read out fault memory	Installation: Transfer staged basic data to the new passenger-side SAM control unit (N10/11).	AD00.00-P-2000-04A
		STAR DIAGNOSIS diagnosis system	*WH58.30-Z-1048-13A
2	Fold back floor covering (1) in passenger footwell		
3	Remove damping material (2) upwards off the footrest (3)		
4	Unscrew nuts (4)		
5	Remove footrest (3) and put down in front passenger footwell		
6	Separate the electrical connectors (5)	The electrical connector (5) leading circuit 30 must be disconnected first and contacted last.	
7	Unscrew screws (6) and remove the passenger-side SAM control unit (N10/11)		
8	Install in the reverse order		

Commercially available tools

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00