

- 2 AUX jack
- 8 Glove compartment



P82.60-5151-11

	Removing		
	Notes on avoiding damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
	Danger!	Risk of explosion caused by escaping oxyhydrogen gas. Risk of injury caused by caustic burns to eyes, skin and mucous membranes from battery electrolyte (contains diluted sulfuric acid) or metal spatter due to short circuit. Risk of burn injuries caused by short circuit. Risk of poisoning caused by swallowing battery electrolyte (contains diluted sulfuric acid) or absorption of lead over the skin or orifices	No fire, sparks, open flames or smoking. Wear acid-resistant gloves and clothing and safety glasses with side guards. Do not place any conductive objects on the battery and avoid any short circuit from battery positive to ground. Only fill liquid battery electrolyte (diluted sulfuric acid) into suitable and appropriately marked containers.
1 	Disconnect battery ground line		AS54.10-Z-0001-01A
	Notes on battery		AR54.10-P-0003SX
	Notes on AGM battery		AH54.10-P-0001-01A
			AH54.10-P-0002-01A
2	Remove COMAND controller unit	Only pull out to front until electrical connectors are accessible.	
3 	Remove glove compartment		AR68.10-P-1400SX
	Install		
4	Retrofit AUX jack wiring harness		AZ82.60-P-0021-01SX
5	Install in the reverse order	Steps 3 to 1.	
6	Enable AUX jack with STAR DIAGNOSIS	Perform variant coding with STAR DIAGNOSIS to activate the AUX function of the COMAND. STAR DIAGNOSIS diagnosis system	*WH58.30-Z-1048-13A
7	Carry out function check	Check AUX function as per operating instructions in vehicle.	

Commercially available tools

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS Compact diagnosis system for passenger cars	6511 1801 00

Parts ordering notes

Part no.	Designation	Quantity
B6 782 3118	Wiring harness for AUX socket	1