
MODEL 207, 212, 218

- 1 Thumbwheel
- 2 Parking brake brake shoe
- 3 Brake disk



P42.20-2513-05

Modification notes

20.7.10	"Perform brake test on test bench" reference changed	Test sequence augmented/revised	
---------	--	---------------------------------	--

X	Removing			
⚠ Danger!	Risk of injury to skin and eyes caused by handling hot or glowing objects.	Wear safety gloves, protective clothing and safety glasses, if necessary.	AS00.00-Z-0002-01A	
(1)	Notes on repairs to brake system		AH42.00-P-0003-01A	
1	Release parking brake			
2	Remove rear wheels	Model 207	AP40.10-P-4050CW	
	Model 212, 218		AP40.10-P-4050EW	
	Adjust			
3	Using a screwdriver turn the right and left adjustment wheel (1) until the brake shoes (2) abut the drums	Turning direction to apply the brake shoes (2): Turn the right adjustment wheel (1) against the direction of travel. Turn the left-hand adjusting wheel (1) in the direction of travel.		
4	Checking			
4	Check brake disks (3) for locking up:	i It must not be possible to turn the brake disks (3) by hand.		
5	Release the left-hand and right-hand adjusting wheel (1)	Release the left-hand and right-hand adjusting wheel (1) by the same number of teeth.	*BE42.20-P-1001-01I	
6	Check brake disks (3) for unobstructed movement:	i It must be possible to turn the brake disks (3) completely freely by hand.		
7	Operate parking brake			
8	Check brake disks (3) for locking up:	i It must not be possible to turn the brake disks (3) by hand.		
9	Release parking brake			
10	Check brake disks (3) for unobstructed movement:	i It must be possible to turn the brake disks (3) completely freely by hand.		
	Install			
11	Fit rear wheels	Model 207	AP40.10-P-4050CW	
		Model 212, 218	AP40.10-P-4050EW	
12	Lower vehicle			
13	Carry out brake test on the test stand		AP42.00-P-4290BA	

Adjustment values for parking brake

Number	Designation	Model 207	Model 212	Model 218

BE42.20-P-1001-01I	Number of teeth by which adjusting wheel of adjusting mechanism must be loosened after the parking brake shoes make contact.	Number of teeth	8	10	10