

<b>VIN</b>	████████████████████	<b>Model series/model designation</b>	164.125
<b>Order number</b>		<b>License plate</b>	

Full list of fault codes and events [SCR=Selective Catalytic Reduction](#)

100200	The difference in the air mass measurement is outside the defined limits.
100700	The upper limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
100800	The upper limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
100900	The lower limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
100A00	The lower limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
100B00	The upper limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
100C00	The upper limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
100D00	The lower limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
100E00	The lower limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
100F00	The upper limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
101000	The upper limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
101100	The lower limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
101200	The lower limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
101300	The upper limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.

12/2016 (2016-10-06)\AddOns: ([6988] (7160) (7258) (6755) (6933) (7418) (7176) (6765) (7292) (6726) (6832) (7030) (6815) (6961) (6892) (6927) (6642) (6882) (6977) (6604) (7100) (7128) (6819) (7134) (7069) (6785) (7229) (6669) (6658) (7309) (7188) (6728) (6569) (6843) (6826) (6818) (6997) (6896) (7172) (7092) (6931) (7084) (6951) (6835) (6691) (7014) (6622) (6792) (6828) (6768) (6985) (6721) (6745) (7154) (6677) (7143) (6817) (6919) (6780) (6707) (6686) (6863) (7002) (6991) (6700) (6615) (6803) (6880) (6580) (6646) (6576) (6986) (6814) (6670) (7009) (7018) (6781) (6673) (6877) (6864) (6872) (7033) (7256) (7318) (6730) (7104) (6663) (7147) (6798) (6994) (6858) (6898) (6871) (7386) (6704) (7029) (6822) (6850) (6796) (7065) (6802) (6971) (6874) (7072) (7082) (6746) (7239) (6772) (6857) (6949) (7180) (6831) (7086) (6627) (6916) (7206) (6742) (7042) (6964) (6870) (7166) (7138) (7080) (7398) (6848) (6975) (7001) (6760) (6679) (6845) (6732) (6565) (6941) (6902) (6890) (6847) (6842) (6856) (7359) (6578) (7007) (7185) (7158) (7026) (6894) (6980) (6739) (7119) (6684) (6995) (6816) (6809) (6784) (6972) (6633) (6952) (6648) (6943) (6793) (6981) (7135) (7036) (6608) (6907) (7023) (6861) (7113) (7433) (7209) (7324) (6954) (7097) (6705) (6825) (6968) (6885) (6616) (6573) (6759) (6676) (6682) (6887) (6910) (7226) (6914) (6866) (7360) (6886) (7233) (7108) (6953) (5226) (7267) (7121) (7201) (7063) (6599) (7049) (7216) (6649) (7055) (6774) (6724) (7225) (6990) (6833) (6965) (6906) (6800) (7251) (6962) (6958) (7068) (7071) (6900) (7316) (7289) (6788) (6851) (6709) (6948) (6983) (6769) (6714) (7190) (6924) (6889) (6921) (6911) (7012) (7150) (5225) (7164) (7198) (6588) (6903) (6697) (6596) (6839) (7058) (6790) (7109) (6787) (7052) (6868) (7300) (6653) (7248) (6884) (7032) (6735) (7046) (6876) (6630) (6806) (6904) (6659) (7458) (6867) (7008) (6946) (7184) (6879) (6841) (6912) (6570) (7142) (7077) (6801) (6618) (6976) (73131))

101400 The upper limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
101500 The lower limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
101600 The lower limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
101700 Component B2/6 (Left hot film mass air flow sensor) has a plausibility error.
101800 Component B2/7 (Right hot film mass air flow sensor) has a plausibility error.
101900 Component B2/6 (Left hot film mass air flow sensor) has a plausibility error.
101A00 Component B2/7 (Right hot film mass air flow sensor) has a plausibility error.
101B00 The signal voltage of sensor 1 of component B37 (Accelerator pedal sensor) is too high.
101C00 The signal voltage of sensor 1 of component B37 (Accelerator pedal sensor) is too low.
101D00 The signal voltage of sensor 2 of component B37 (Accelerator pedal sensor) is too high.
101E00 The signal voltage of sensor 2 of component B37 (Accelerator pedal sensor) is too low.
101F00 Component B37 (Accelerator pedal sensor) has a plausibility error.
102000 The reference voltage of component B37 (Accelerator pedal sensor) is implausible.
102100 Control module has an internal error.
102900 The water content of the fuel filter has reached the upper limit value.
102B00 Shutoff of injection quantity to prevent resonance of four-mass flywheel.
102C00 The signal from component B76 (Fuel filter condensation sensor) is faulty.
102D00 Control module has an internal error.
102E00 The signal of circuit 15 is implausible.
102F00 The signal of circuit 15 is implausible.
103100 The positive control deviation of exhaust gas recirculation control is too high.
103200 The negative control deviation of exhaust gas recirculation control is too high.
103300 The positive control deviation of exhaust gas recirculation control during regeneration is too high.
103400 The negative control deviation of exhaust gas recirculation control during regeneration is too high.
103500 Timeout during transition from regeneration to normal operation
103D00 The dynamic test of component B11/4 (Coolant temperature sensor) was not successful.
103E00 The signal voltage of component B11/4 (Coolant temperature sensor) is too high.
103F00 The signal voltage of component B11/4 (Coolant temperature sensor) is too low.
104200 Internal control module error
104300 Component S40/3 (Clutch pedal switch) has a plausibility error.
104400 The signal from component S40/3 (Clutch pedal switch) is faulty.
104C00 The difference between the current measurement and the most recent measurement of the exhaust gas temperature from component B19 (Catalytic converter temperature sensor) is too great.

104D00	The difference between the current measurement and the most recent measurement of the exhaust gas temperature from component B19/9 (Temperature sensor upstream of diesel particulate filter) is too great.
104F00	Component Y85 (Exhaust gas recirculation cooler bypass switchover valve) has Open circuit.
105000	Component Y85 (Exhaust gas recirculation cooler bypass switchover valve) has Short circuit to positive.
105100	Component Y85 (Exhaust gas recirculation cooler bypass switchover valve) has Short circuit to ground.
105500	Component Y27/9 (Left EGR positioner) has Open circuit.
105600	Component Y27/9 (Left EGR positioner) has Short circuit to positive.
105700	Component Y27/9 (Left EGR positioner) has Short circuit to ground.
105800	The requirements of control unit N30/4 (Electronic Stability Program control unit) for increasing the idle speed are not fulfilled.
105E00	One or more signals sent from control unit A1 (Instrument cluster) via the CAN bus is implausible.
105F00	One or more signals sent from control unit A1 (Instrument cluster) via the CAN bus is implausible.
106000	One or more signals sent from control unit A1 (Instrument cluster) via the CAN bus is implausible.
106100	The upper limit value for long-term adaptation of the SCR exhaust aftertreatment system was exceeded.
106200	The lower limit value for long-term adaptation of the SCR exhaust aftertreatment system was dropped below.
106300	Efficiency of SCR catalytic converter : Effect is insufficient.
106400	Efficiency of SCR catalytic converter : Effect is insufficient.
106600	Component NOx sensor downstream of SCR catalytic converter has a plausibility error.
106700	The AdBlue tank is empty.
106900	The engine speed is too high.
106A00	The engine speed is too low.
106B00	Component R48 (Coolant thermostat heating element) has excess temperature.
106C00	The efficiency of the catalytic converter (cylinder bank 1) is not sufficient.
106D00	This function is not available at present.
107A00	This function is not available at present.
107B00	One or more signals sent from control unit A1 (Instrument cluster) via the CAN bus is implausible.
107C00	Plausibility error between signal of temperature sensor in intake pipe and signal of outside temperature sensor
107D00	The oxygen sensor heater has overtemperature.
107E00	The upper limit value of component B28/8 (Differential pressure sensor (DPF)) has been reached.
107F00	The upper limit value of component B19 (Catalytic converter temperature sensor) has been exceeded.

108000	The upper limit value of component B19/9 (Temperature sensor upstream of diesel particulate filter) has been exceeded.
108100	The lower limit value of component B28/8 (Differential pressure sensor (DPF)) has been reached.
108200	The lower limit value of component B19 (Catalytic converter temperature sensor) was dropped below/not reached.
108300	The lower limit value of component B19/9 (Temperature sensor upstream of diesel particulate filter) was dropped below/not reached.
108400	The signal voltage of component Atmospheric pressure sensor is too high.
108500	The signal voltage of component Atmospheric pressure sensor is too low.
108600	The signal voltage of component B14 (Outside temperature sensor) is too high.
108700	The signal voltage of component B14 (Outside temperature sensor) is too low.
108800	The signal from component B6/1 (Camshaft Hall sensor) is faulty.
108900	No signal from component B6/1 (Camshaft Hall sensor)
108A00	No signal from component B70 (Crankshaft Hall sensor)
108B00	The signal from component B70 (Crankshaft Hall sensor) is faulty.
108C00	The difference between the measured temperature and the calculated temperature of component B19 (Catalytic converter temperature sensor) is too great.
108D00	The difference between the measured temperature and the calculated temperature of component B19/9 (Temperature sensor upstream of diesel particulate filter) is too great.
108E00	The difference between the measured exhaust gas temperature from component B19 (Catalytic converter temperature sensor) and from component B19/9 (Temperature sensor upstream of diesel particulate filter) is too great.
108F00	Component Y94 (Quantity control valve) has excess temperature.
109000	Component R48 (Coolant thermostat heating element) has excess temperature.
109100	This function is not available at present.
109800	The signal voltage of component B50 (Fuel temperature sensor) is too high.
109900	The signal voltage of component B50 (Fuel temperature sensor) is too low.
109A00	Component G2 (generator) has a malfunction.
109C00	The maximum rail pressure was exceeded.
109D00	The minimum rail pressure was dropped below/not reached.
109E00	The minimum rail pressure was dropped below/not reached.
109F00	The maximum rail pressure was exceeded.
10A000	The number of combustion misfires at cylinder 6 is too high.
10A100	The number of combustion misfires at cylinder 1 is too high.
10A200	The number of combustion misfires at cylinder 4 is too high.
10A300	The number of combustion misfires at cylinder 2 is too high.
10A400	The number of combustion misfires at cylinder 5 is too high.
10A500	The number of combustion misfires at cylinder 3 is too high.
10A600	The number of combustion misfires at cylinder 6 is too high.
10A800	Component is not installed.
10A900	Component is not installed.
10AA00	Component is not installed.

10AB00	Component is not installed.
10AC00	Component B16/15 (Temperature sensor upstream of SCR catalytic converter) has a plausibility error.
10AD00	This function is not yet supported by the control unit.
10AE00	This function is not yet supported by the control unit.
10AF00	Component B16/15 (Temperature sensor upstream of SCR catalytic converter) has a plausibility error.
10B000	This function is not yet supported by the control unit.
10B100	This function is not yet supported by the control unit.
10B200	Component B19/11 (Temperature sensor upstream of turbocharger) has a plausibility error.
10B300	Component B19 (TWC temperature sensor) has a plausibility error.
10B400	Component B19/9 (Temperature sensor upstream of diesel particulate filter) has a plausibility error.
10B500	Component B16/15 (Temperature sensor upstream of SCR catalytic converter) has a plausibility error.
10B600	This function is not yet supported by the control unit.
10B700	This function is not yet supported by the control unit.
10B800	Component Exhaust temperature sensor has a plausibility error.
10B900	Component B16/15 (Temperature sensor upstream of SCR catalytic converter) has a plausibility error.
10BA00	This function is not yet supported by the control unit.
10BE00	This function is not yet supported by the control unit.
10BF00	The control line to component M4/7 (Engine and AC electric suction fan with integrated control) has Open circuit.
10C000	Component M4/7 (Engine and AC electric suction fan with integrated control) has Excess temperature.
10C100	The control line to component M4/7 (Engine and AC electric suction fan with integrated control) has Short circuit to positive.
10C200	The control line to component M4/7 (Engine and AC electric suction fan with integrated control) has Short circuit to ground.
10C300	Component B5/1 (Charge pressure sensor) has a plausibility error.
10C400	The signal voltage of component B5/1 (Charge pressure sensor) is too high.
10C500	The signal voltage of component B5/1 (Charge pressure sensor) is too low.
10C700	Component B96/1 (Left intake port shutoff end position sensor) is defective.
10C800	Component B96/2 (Right intake port shutoff end position sensor) is defective.
10CA00	Component B96/1 (Left intake port shutoff end position sensor) is defective.
10CB00	Component B96/2 (Right intake port shutoff end position sensor) is defective.
10CC00	Component is not installed.
10CD00	Check component Exhaust gas recirculation cooler.
10CE00	Control module has an internal error.
10CF00	There is an internal fault in component G3/2 (O2 sensor upstream of KAT).
10D000	There is an internal fault in component G3/2 (O2 sensor upstream of KAT).
10D100	There is an internal fault in component B4/6 (Rail pressure sensor).

10D300	Adjustment of injector injection quantities Cylinder 1
10D400	Adjustment of injector injection quantities Cylinder 4
10D500	Adjustment of injector injection quantities Cylinder 2
10D600	Adjustment of injector injection quantities Cylinder 5
10D700	Adjustment of injector injection quantities Cylinder 3
10D800	Adjustment of injector injection quantities Cylinder 6
10D900	The coolant temperature is below the coolant thermostat specified temperature.
10DA00	Component B11/4 (Coolant temperature sensor) has a plausibility error.
10DB00	The dynamic test of component B11/4 (Coolant temperature sensor) was not successful.
10DC00	Component Y76/1 (Cylinder 1 fuel injector) has Open circuit.
10DD00	Component Y76/4 (Fuel injector cylinder 4) has Open circuit.
10DE00	Component Y76/2 (Cylinder 2 fuel injector) has Open circuit.
10DF00	Component Y76/5 (Fuel injector cylinder 5) has Open circuit.
10E000	Component Y76/3 (Cylinder 3 fuel injector) has Open circuit.
10E100	Component Y76/6 (Fuel injector cylinder 6) has Open circuit.
10E200	The number of combustion misfires at cylinder 1 is too high.
10E300	The number of combustion misfires at cylinder 4 is too high.
10E400	The number of combustion misfires at cylinder 2 is too high.
10E500	The number of combustion misfires at cylinder 5 is too high.
10E600	The number of combustion misfires at cylinder 3 is too high.
10E700	The number of combustion misfires at cylinder 6 is too high.
10E800	The number of combustion misfires is too high at several cylinders.
10E900	Control module has an internal error.
10EA00	Control module has an internal error.
10EB00	Control module has an internal error.
10EC00	Control module has an internal error.
10ED00	Control module has an internal error.
10EE00	Control module has an internal error.
10EF00	Component B16/14 (Exhaust gas recirculation temperature sensor) has a plausibility error.
10F100	The maximum rail pressure was exceeded.
10F200	Value is below negative deviation.
10F300	Value is below negative deviation.
10F400	The maximum rail pressure was exceeded.
10F500	The maximum rail pressure was exceeded.
10F600	This function is not yet supported by the control unit.
10F700	The number of combustion misfires at cylinder 1 is too high.
10F800	The number of combustion misfires at cylinder 4 is too high.
10F900	The number of combustion misfires at cylinder 2 is too high.
10FA00	The number of combustion misfires at cylinder 5 is too high.
10FB00	The number of combustion misfires at cylinder 3 is too high.

10FC00	This function is not available at present.
10FD00	This function is not available at present.
10FE00	This function is not available at present.
10FF00	A fault was detected during regeneration of the diesel particulate filter.
110000	A fault was detected during regeneration of the diesel particulate filter.
110100	Control module has an internal error.
110200	There is an internal control unit fault in the digital/digital converter.
110300	There is an internal control unit fault in the digital/digital converter.
110400	There is an internal fault in component G3/2 (O2 sensor upstream of KAT).
110500	There is an internal fault in component G3/2 (O2 sensor upstream of KAT).
110600	The number of injections is limited because the fill level is too high.
110700	The number of injections is limited because the injection quantity is too low.
110800	The number of injections is limited because the software is incorrect.
110900	There is an internal fault in component G3/2 (O2 sensor upstream of KAT).
110F00	Control module has an internal error.
111000	The supply voltage of component NOx sensor downstream of SCR catalytic converter is too low (undervoltage).
111100	There is an internal fault in component G3/2 (O2 sensor upstream of KAT).
111200	The supply voltage of component NOx sensor upstream of SCR catalytic converter is too low (undervoltage).
111300	Control module has an internal error.
111400	This function is not available at present.
111500	The regeneration frequency of the diesel or gasoline particulate filter is not OK.
111600	Regeneration of the diesel particulate filter was aborted.
111700	Excessive nitrogen oxide emission due to low quality AdBlue
111800	The upper limit value of component NOx sensor downstream of SCR catalytic converter has been exceeded.
111900	The lower limit value of component NOx sensor downstream of SCR catalytic converter was dropped below/not reached.
111A00	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
111B00	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
111C00	The upper limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
111D00	Component G3/2 (Oxygen sensor upstream of catalytic converter) has Open circuit.
111E00	The upper limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
111F00	The upper limit value of component B2/6 (Left hot film mass air flow sensor) has been reached.
112000	The upper limit value of component B2/7 (Right hot film mass air flow sensor) has been reached.
112900	Component G3/2 (Oxygen sensor upstream of catalytic converter) has Open circuit.
113100	Component G3/2 (Oxygen sensor upstream of catalytic converter) has a plausibility error.
113200	Component is not installed.

113500	Component G3/2 (Oxygen sensor upstream of catalytic converter) has a malfunction.
113600	Component is not installed.
113900	The heater for component G3/2 (Oxygen sensor upstream of catalytic converter) has a short circuit to positive.
113A00	Component is not installed.
113D00	The heater for component G3/2 (Oxygen sensor upstream of catalytic converter) has a short circuit to positive.
113E00	Component is not installed.
114500	The heater for component G3/2 (Oxygen sensor upstream of catalytic converter) has an open circuit.
114600	Component is not installed.
114900	The signal voltage of component G3/2 (Oxygen sensor upstream of catalytic converter) is too high.
114A00	Component is not installed.
114D00	The signal voltage of component G3/2 (Oxygen sensor upstream of catalytic converter) is too low.
114E00	Component is not installed.
115100	The signal voltage of component G3/2 (Oxygen sensor upstream of catalytic converter) is too high.
115200	Component is not installed.
115500	The signal voltage of component G3/2 (Oxygen sensor upstream of catalytic converter) is too low.
115600	Component is not installed.
116100	The resistance value of the oxygen sensor exceeds the upper limit value during calibration.
116200	Component is not installed.
116500	The resistance value of the oxygen sensor drops below the lower limit value during calibration.
116600	Component is not installed.
116900	An internal component of the oxygen sensor has insufficient supply voltage.
116A00	Component is not installed.
116D00	There is an internal fault in component G3/2 (Oxygen sensor upstream of catalytic converter).
116E00	Component is not installed.
117100	There is an internal fault in component G3/2 (Oxygen sensor upstream of catalytic converter).
117200	Component is not installed.
117500	The upper limit value for the temperature at the sensor of component G3/2 (Oxygen sensor upstream of catalytic converter) has been exceeded.
117600	Component is not installed.
117900	The lower limit value for the temperature at the sensor of component G3/2 (Oxygen sensor upstream of catalytic converter) has been dropped below.
117A00	Component is not installed.



118000	Relay N10/1kR (Chassis circuit 87 relay) of component N10/1 (Front SAM control unit with fuse and relay module) switches off too early.
118100	Relay N10/1kR (Chassis circuit 87 relay) of component N10/1 (Front SAM control unit with fuse and relay module) switches off too late.
118200	Component Y94 (Quantity control valve) has Open circuit.
118300	Component Y94 (Quantity control valve) has Short circuit to positive.
118400	Component Y94 (Quantity control valve) has Short circuit to ground.
118500	There is an internal fault in component Y94 (Quantity control valve).
118600	There is an internal fault in component Y94 (Quantity control valve).
118700	The signal from component B28/8 (Differential pressure sensor (DPF)) is implausible.
118800	The signal from component Atmospheric pressure sensor is implausible.
118900	Component B60 (Exhaust back pressure sensor) has a plausibility error.
118A00	Plausibility error due to defective exhaust gas pressure lines between diesel particulate filter and differential pressure sensor
118B00	Component <b>B28/5</b> (Pressure sensor downstream of air filter) has a plausibility error.
118C00	Component B60 (Exhaust back pressure sensor) has a plausibility error.
118D00	Component B28/8 (Differential pressure sensor (DPF)) has a plausibility error.
119100	Component B19/9 (Temperature sensor upstream of diesel particulate filter) has a plausibility error.
119400	The oil level of the combustion engine is implausible.
119A00	The upper limit value of component B1 (Oil temperature sensor) has been reached.
119B00	Component B1 (Oil temperature sensor) has a plausibility error.
119F00	The positive control deviation during boost pressure control is too high.
11A000	The negative control deviation during boost pressure control is too high.
11A100	Component Y74 (Pressure control valve) has Open circuit.
11A200	Component Y74 (Pressure control valve) has Short circuit to positive.
11A300	Component Y74 (Pressure control valve) has Short circuit to ground.
11A400	The lower limit value of component Y74 (Pressure control valve) was dropped below/not reached.
11A500	The upper limit value of component Y74 (Pressure control valve) has been exceeded.
11A700	The fill level of the diesel particulate filter is too high.
11A800	The pressure differential in the diesel particulate filter is too high.
11AA00	The ash content of the diesel particulate filter is implausible.
11AB00	Regeneration of the diesel particulate filter is permanently active.
11AC00	The air mass in the diesel particulate filter is too high.
11AD00	The air mass in the diesel particulate filter is too low.
11B100	Component M3 (Fuel pump) has Open circuit.
11B200	Component M3 (Fuel pump) has Short circuit to positive.
11B300	Component M3 (Fuel pump) has Short circuit to ground.
11B400	The control unit reports a plausibility error during quantity correction.
11B500	Component Y74 (Pressure control valve) has a plausibility error.
11B600	The minimum rail pressure was dropped below/not reached.

MAP Sensor

	11B700 The maximum rail pressure was exceeded.
	11B800 The control deviation during rail pressure regulation via the quantity control valve is too high.
	11B900 The control deviation during rail pressure regulation via the quantity control valve is too high.
	11BA00 The control deviation during rail pressure regulation via the quantity control valve is too high.
	11BB00 The rail pressure is too low during regulation via the quantity control valve.
	11BC00 The rail pressure is too high during regulation via the quantity control valve.
	11BD00 The control deviation during rail pressure regulation via the pressure regulator valve is too high.
	11BE00 The control deviation during rail pressure regulation via the pressure regulator valve is too high.
	11BF00 The control deviation during rail pressure regulation via the pressure regulator valve (in closed state) is too high.
	11C000 The rail pressure is too low during regulation via the pressure regulator valve.
	11C100 The rail pressure is too high during regulation via the pressure regulator valve.
	11C300 The upper limit value of component B4/6 (Rail pressure sensor) has been exceeded.
	11C400 The lower limit value of component B4/6 (Rail pressure sensor) was dropped below/not reached.
	11C500 The signal voltage of component B4/6 (Rail pressure sensor) is too high.
	11C600 The signal voltage of component B4/6 (Rail pressure sensor) is too low.
MAP Sensor	11D000 The signal voltage of component B28/5 (Pressure sensor downstream of air filter) is too high.
	11D100 The signal voltage of component B28/8 (Differential pressure sensor (DPF)) is too high.
	11D300 The signal voltage of component B60 (Exhaust back pressure sensor) is too high.
	11D400 The signal voltage of the internal temperature sensor of the control unit is too high.
	11D700 The upper limit value of component B19/9 (Temperature sensor upstream of diesel particulate filter) has been exceeded.
MAP Sensor	11D900 The lower limit value of component B28/5 (Pressure sensor downstream of air filter) was dropped below/not reached.
	11DA00 The lower limit value of component B28/8 (Differential pressure sensor (DPF)) was dropped below/not reached.
	11DC00 The lower limit value of component B60 (Exhaust back pressure sensor) was dropped below/not reached.
	11DD00 The signal voltage of the internal temperature sensor of the control unit is too low.
	11E000 The lower limit value of component B19/9 (Temperature sensor upstream of diesel particulate filter) was dropped below/not reached.
	11E600 An internal control unit reset was performed.
	11E700 An internal control unit reset was performed.
	11E900 Start attempt without starter actuation
	11EA00 Starter control has open circuit.
	11EB00 Starter control has short circuit to positive.

11EC00	Starter control has short circuit to ground.
11EE00	The signal of circuit 50 (CAN) is implausible.
11EF00	The upper limit value of component B2/6b1 (Left intake air temperature sensor) has been exceeded.
11F000	The upper limit value of component B2/7b1 (Right intake air temperature sensor) has been exceeded.
11F100	The lower limit value of component B2/6b1 (Left intake air temperature sensor) was dropped below/not reached.
11F200	The lower limit value of component B2/7b1 (Right intake air temperature sensor) was dropped below/not reached.
11F300	The signal voltage of component B2/6b1 (Left intake air temperature sensor) is too high.
11F400	The signal voltage of component B2/7b1 (Right intake air temperature sensor) is too high.
11F500	The signal voltage of component B2/6b1 (Left intake air temperature sensor) is too low.
11F600	The signal voltage of component B2/7b1 (Right intake air temperature sensor) is too low.
11F700	The upper limit value of component B2/6b1 (Left intake air temperature sensor) has been exceeded.
11F800	The upper limit value of component B2/7b1 (Right intake air temperature sensor) has been exceeded.
11F900	The upper limit value of component B2/6b1 (Left intake air temperature sensor) has been exceeded.
11FA00	The upper limit value of component B2/7b1 (Right intake air temperature sensor) has been exceeded.
11FB00	The signal voltage of component B17/8 (Charge air temperature sensor) is too high.
11FC00	The signal voltage of component B17/8 (Charge air temperature sensor) is too low.
120300	The limit value of component M16/6 (Throttle valve actuator) is exceeded due to offset drift.
120400	Component M16/6 (Throttle valve actuator) has Open circuit.
120600	Component M16/6 (Throttle valve actuator) has Short circuit to positive.
120700	Component M16/6 (Throttle valve actuator) has Short circuit to ground.
120800	The signal voltage of component M16/6 (Throttle valve actuator) is too high.
120900	The signal voltage of component M16/6 (Throttle valve actuator) is too low.
120A00	The limit value of component M16/6 (Throttle valve actuator) is exceeded due to offset drift.
120B00	Component Y77/1 (Charge pressure positioner) has Open circuit.
120C00	Component Y77/1 (Charge pressure positioner) has Short circuit to positive.
120D00	Component Y77/1 (Charge pressure positioner) has Short circuit to ground.
121000	The plausibility check for the torque request from control unit A89 (DISTRONIC electric controller unit) was not performed.
121100	The plausibility check for the torque request from control unit N30/4 (Electronic Stability Program control unit) was not performed.

121200	The plausibility check for the torque request from control unit Transmission control was not performed.
121300	Component M55 (Intake port shutoff actuator motor) has Open circuit.
121400	Component M55 (Intake port shutoff actuator motor) has Short circuit to positive.
121500	Component M55 (Intake port shutoff actuator motor) has Short circuit to ground.
122300	The minimum rail pressure was dropped below/not reached.
122400	The upper limit value for injector voltage has been exceeded.
122500	The lower limit value for injector voltage has been dropped below.
122C00	Component Y76/1 (Cylinder 1 fuel injector) is faulty.
122D00	Component Y76/4 (Fuel injector cylinder 4) is faulty.
122E00	Component Y76/2 (Cylinder 2 fuel injector) is faulty.
122F00	Component Y76/5 (Fuel injector cylinder 5) is faulty.
123000	Component Y76/3 (Cylinder 3 fuel injector) is faulty.
123100	Component Y76/6 (Fuel injector cylinder 6) is faulty.
123900	Charge pressure is too low.
123A00	The negative control deviation during boost pressure control is too high.
123B00	A fault was detected during regeneration of the diesel particulate filter.
123C00	A fault occurred during signal transmission from control unit N3/9 (CDI control unit) to control unit N73 (Electronic ignition lock control unit).
123D00	There is an internal fault in system 'Immobilizer'.
123E00	The value for authentication in system 'Immobilizer' is invalid.
123F00	A locked key was detected by system 'Immobilizer'.
124600	The supply voltage to the sensors is outside the valid range.
124700	The supply voltage to the sensors is outside the valid range.
124800	The supply voltage to the sensors is outside the valid range.
124F00	Component Y27/9 (Left EGR positioner) is faulty.
125000	Component Y27/9 (Left EGR positioner) is faulty.
125C00	The positive control deviation during boost pressure control is too high.
125E00	The negative control deviation during boost pressure control is too high.
126000	Component is not installed.
126100	Component is not installed.
126200	Component is not installed.
126300	Component is not installed.
126400	Component is not installed.
126500	Component is not installed.
126600	Component is not installed.
126700	Component is not installed.
126800	Component Y77/1 (Charge pressure positioner) is faulty.
126900	Component Y77/1 (Charge pressure positioner) is faulty.
126A00	Component M55 (Intake port shutoff actuator motor) is faulty.
126B00	Component M55 (Intake port shutoff actuator motor) is faulty.
126C00	The number of injections is limited due to the engine running time.

126D00	The values for injector injection quantity adjustment (cylinder 1) are faulty.
126E00	The values for injector injection quantity adjustment (cylinder 4) are faulty.
126F00	The values for injector injection quantity adjustment (cylinder 2) are faulty.
127000	The values for injector injection quantity adjustment (cylinder 5) are faulty.
127100	The values for injector injection quantity adjustment (cylinder 3) are faulty.
127200	The values for injector injection quantity adjustment (cylinder 6) are faulty.
127900	The switch for selecting the injector bank in the control unit has a short circuit (injector bank 1).
127A00	The switch for selecting the injector bank in the control unit has a short circuit (injector bank 2).
128D00	The engine speed is too high.
129200	The soot content of the diesel particulate filter is implausible.
129300	The soot content of the diesel particulate filter is implausible.
129400	The soot content of the diesel particulate filter is implausible.
129600	Component B28/8 (Differential pressure sensor (DPF)) reports a fault due to swapped connections.
129700	The diesel particulate filter is defective.
129A00	The position of the camshaft is implausible compared with the position of the crankshaft.
12BC00	Component B28/8 (Differential pressure sensor (DPF)) has a plausibility error.
12BD00	The control deviation during rail pressure regulation via the quantity control valve is too high. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
12BE00	The control deviation during rail pressure regulation via the quantity control valve is too high. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
12C000	Component is not installed.
12C100	Component is not installed.
12C300	The difference between the measured temperature and the calculated temperature of component B19 (Catalytic converter temperature sensor) is too great.
12C400	The difference between the measured temperature and the calculated temperature of component B19/9 (Temperature sensor upstream of diesel particulate filter) is too great.
12C500	Component is not installed.
12CA00	The energy consumption of the fuel injector of cylinder 1 has exceeded the upper limit value.
12CB00	The energy consumption of the fuel injector of cylinder 4 has exceeded the upper limit value.
12CC00	The energy consumption of the fuel injector of cylinder 2 has exceeded the upper limit value.
12CD00	The energy consumption of the fuel injector of cylinder 5 has exceeded the upper limit value.
12CE00	The energy consumption of the fuel injector of cylinder 3 has exceeded the upper limit value.
12CF00	The energy consumption of the fuel injector of cylinder 6 has exceeded the upper limit value.

12D000	The energy consumption of the fuel injector of cylinder 1 has dropped below the lower limit value.
12D100	The energy consumption of the fuel injector of cylinder 4 has dropped below the lower limit value.
12D200	The energy consumption of the fuel injector of cylinder 2 has dropped below the lower limit value.
12D300	The energy consumption of the fuel injector of cylinder 5 has dropped below the lower limit value.
12D400	The energy consumption of the fuel injector of cylinder 3 has dropped below the lower limit value.
12D500	The energy consumption of the fuel injector of cylinder 6 has dropped below the lower limit value.
12D600	The energy consumption of the fuel injector of cylinder 1 is implausible.
12D700	The energy consumption of the fuel injector of cylinder 4 is implausible.
12D800	The energy consumption of the fuel injector of cylinder 2 is implausible.
12D900	The energy consumption of the fuel injector of cylinder 5 is implausible.
12DA00	The energy consumption of the fuel injector of cylinder 3 is implausible.
12DB00	The energy consumption of the fuel injector of cylinder 6 is implausible.
12E200	Control module has an internal error.
12E300	Control module has an internal error.
12E500	Injector bank 1 has a short circuit.
12E600	Injector bank 2 has a short circuit.
12ED00	The fuel injector of cylinder 1 has a short circuit.
12EE00	The fuel injector of cylinder 4 has a short circuit.
12EF00	The fuel injector of cylinder 2 has a short circuit.
12F000	The fuel injector of cylinder 5 has a short circuit.
12F100	The fuel injector of cylinder 3 has a short circuit.
12F200	The fuel injector of cylinder 6 has a short circuit.
12F300	The fuel injector of cylinder 1 has a short circuit between positive and ground.
12F400	The fuel injector of cylinder 4 has a short circuit between positive and ground.
12F500	The fuel injector of cylinder 2 has a short circuit between positive and ground.
12F600	The fuel injector of cylinder 5 has a short circuit between positive and ground.
12F700	The fuel injector of cylinder 3 has a short circuit between positive and ground.
12F800	The fuel injector of cylinder 6 has a short circuit between positive and ground.
12FA00	Component G3/2 (Oxygen sensor upstream of catalytic converter) has Short circuit to positive.
12FB00	Component is not installed.
12FE00	Component G3/2 (Oxygen sensor upstream of catalytic converter) has Short circuit to ground.
12FF00	Component is not installed.
130200	Control module has an internal error.
130300	Control module has an internal error.
130400	Control module has an internal error.

130500	Control module has an internal error.
130600	Control module has an internal error.
130800	Control module has an internal error.
130900	Control module has an internal error.
130A00	Control module has an internal error.
130B00	The engine torque is implausible.
130C00	Control module has an internal error.
130D00	Control module has an internal error.
130E00	Control module has an internal error.
130F00	The learned value of the pressure regulator valve has exceeded the upper limit value.
131000	The learned value of the pressure regulator valve has dropped below the lower limit value.
131100	The control deviation during rail pressure regulation is too high.
131200	The control deviation during rail pressure regulation via the quantity control valve is too high.
131300	The control deviation during rail pressure regulation is too high.
131400	The control deviation during rail pressure regulation via the pressure regulator valve is too high.
131500	The maximum rail pressure was exceeded.
131700	Fault when reading the EEPROM
131A00	Component B19/11 (Temperature sensor upstream of turbocharger) has a plausibility error. <a href="#">Part # for US 000 905 42 05</a> <a href="#">ROW 000 905 51 05</a>
131C00	The upper limit value of component B19/11 (Temperature sensor upstream of turbocharger) has been exceeded.
131D00	The lower limit value of component B19/11 (Temperature sensor upstream of turbocharger) was dropped below/not reached.
131E00	Rail pressure deviation due to air forming in the system when the fuel tank is run empty
131F00	Component Y74 (Pressure control valve) has a plausibility error. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
132000	The minimum rail pressure was dropped below/not reached. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
132300	The rail pressure is too low during regulation via the quantity control valve. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
132400	The control deviation during rail pressure regulation is too high. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
132500	The control deviation during rail pressure regulation via the pressure regulator valve is too high. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
132600	The minimum rail pressure was dropped below/not reached. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
132700	This function is not yet supported by the control unit.
132800	The signal voltage of component B16/15 (Temperature sensor upstream of SCR catalytic converter) is too high.

132B00	Check component B19/9 (Temperature sensor upstream of diesel particulate filter).
132C00	This function is not yet supported by the control unit.
132D00	This function is not yet supported by the control unit.
132E00	The signal voltage of component B16/15 (Temperature sensor upstream of SCR catalytic converter) is too low.
133000	The upper limit value of component NOx sensor upstream of SCR catalytic converter has been reached.
133100	The lower limit value of component NOx sensor upstream of SCR catalytic converter was dropped below/not reached.
133200	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
133B00	Check component B2/6 (Left hot film mass air flow sensor).
133C00	Check component B2/7 (Right hot film mass air flow sensor).
134100	This function is not yet supported by the control unit.
134200	This function is not yet supported by the control unit.
134400	Component NOx sensor downstream of SCR catalytic converter has Open circuit.
134500	Component NOx sensor downstream of SCR catalytic converter has a short circuit.
134600	Component NOx sensor upstream of SCR catalytic converter has Open circuit.
134700	Component NOx sensor upstream of SCR catalytic converter has a short circuit.
134800	No CAN message received from component NOx sensor downstream of SCR catalytic converter.
134900	No CAN message received from component NOx sensor upstream of SCR catalytic converter.
134A00	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
134B00	The upper limit value of component NOx sensor upstream of SCR catalytic converter has been exceeded.
134C00	The lower limit value of component NOx sensor upstream of SCR catalytic converter was dropped below/not reached.
134D00	The upper limit value of component NOx sensor upstream of SCR catalytic converter has been exceeded.
134E00	The lower limit value of component NOx sensor upstream of SCR catalytic converter was dropped below/not reached.
134F00	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
135000	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
135100	Signal of component NOx sensor upstream of SCR catalytic converter is not within the valid range.
135200	Signal of component NOx sensor upstream of SCR catalytic converter is not within the valid range.
135300	Component NOx sensor upstream of SCR catalytic converter has an open circuit in the wiring.
135400	Short circuit in component NOx sensor upstream of SCR catalytic converter
135500	Check component B19/9 (Temperature sensor upstream of diesel particulate filter).
135600	This function is not yet supported by the control unit.
135900	This function is not yet supported by the control unit.
135A00	This function is not available at present.



13A800	The exhaust gas temperature is too low.
13A900	The exhaust-gas temperature is too high.
13AA00	The supply voltage of control unit N3/9 (CDI control unit) is too high (overvoltage).
13AB00	The supply voltage of control unit N3/9 (CDI control unit) is too low (undervoltage).
13AC00	The output stage of the heater for the crankcase ventilation system has a short circuit to positive.
13AD00	The output stage of the heater for the crankcase ventilation system has a short circuit to ground.
13AE00	The heater for the crankcase ventilation system has a fault at the output stage.
13AF00	The soot content of the diesel particulate filter is too high.
13B000	There is an internal control unit fault in the analog/digital converter.
13B100	There is an internal control unit fault in the analog/digital converter.
13B200	There is an internal control unit fault in the analog/digital converter.
13B300	There is an internal control unit fault in the analog/digital converter.
13B400	There is an internal control unit fault in the ROM memory.
13B500	There is an internal control unit fault in the ROM memory.
13B600	There is an internal control unit fault in the ROM memory.
13B700	Manual regeneration must be deactivated.
13B800	Soiling limit of air cleaner is reached.
13B900	The control deviation during rail pressure regulation via the quantity control valve is too high. Rail pressure deviation due to air forming in the system when the fuel tank is run empty
13BA00	Maximum actuation duration for zero quantity calibration for injector of cylinder 1 exceeded
13BB00	Maximum actuation duration for zero quantity calibration for injector of cylinder 4 exceeded
13BC00	Maximum actuation duration for zero quantity calibration for injector of cylinder 2 exceeded
13BD00	Maximum actuation duration for zero quantity calibration for injector of cylinder 5 exceeded
13BE00	Maximum actuation duration for zero quantity calibration for injector of cylinder 3 exceeded
13BF00	Maximum actuation duration for zero quantity calibration for injector of cylinder 6 exceeded
13C000	Minimum actuation duration for zero quantity calibration for injector of cylinder 1 not reached
13C100	Minimum actuation duration for zero quantity calibration for injector of cylinder 4 not reached
13C200	Minimum actuation duration for zero quantity calibration for injector of cylinder 2 not reached
13C300	Minimum actuation duration for zero quantity calibration for injector of cylinder 5 not reached
13C400	Minimum actuation duration for zero quantity calibration for injector of cylinder 3 not reached

13C500	Minimum actuation duration for zero quantity calibration for injector of cylinder 6 not reached
13C600	Component N14/3 (Glow output stage) has excess temperature.
13C700	Component N14/3 (Glow output stage) has a malfunction.
13C800	The supply voltage of component N14/3 (Glow output stage) is too low (undervoltage).
13C900	There is an internal fault in component N14/3 (Glow output stage).
13CA00	Component R9/1 (Cylinder 1 glow plug) has Open circuit.
13CB00	Component R9/2 (Cylinder 2 glow plug) has Open circuit.
13CC00	Component R9/3 (Cylinder 3 glow plug) has Open circuit.
13CD00	Component R9/4 (Cylinder 4 glow plug) has Open circuit.
13CE00	Component R9/5 (Glow plug cylinder 5) has Open circuit.
13CF00	Component R9/6 (Cylinder 6 glow plug) has Open circuit.
13D000	Component is not installed.
13D100	Component is not installed.
13D200	The resistance of the glow plug at cylinder R9/1 (Cylinder 1 glow plug) is outside the permissible range.
13D300	The resistance of the glow plug at cylinder R9/2 (Cylinder 2 glow plug) is outside the permissible range.
13D400	The resistance of the glow plug at cylinder R9/3 (Cylinder 3 glow plug) is outside the permissible range.
13D500	The resistance of the glow plug at cylinder R9/4 (Cylinder 4 glow plug) is outside the permissible range.
13D600	The resistance of the glow plug at cylinder R9/5 (Glow plug cylinder 5) is outside the permissible range.
13D700	The resistance of the glow plug at cylinder R9/6 (Cylinder 6 glow plug) is outside the permissible range.
13D800	Component is not installed.
13D900	Component is not installed.
13DA00	Component R9/1 (Cylinder 1 glow plug) has Short circuit to ground.
13DB00	Component R9/2 (Cylinder 2 glow plug) has Short circuit to ground.
13DC00	Component R9/3 (Cylinder 3 glow plug) has Short circuit to ground.
13DD00	Component R9/4 (Cylinder 4 glow plug) has Short circuit to ground.
13DE00	Component R9/5 (Glow plug cylinder 5) has Short circuit to ground.
13DF00	Component R9/6 (Cylinder 6 glow plug) has Short circuit to ground.
13E000	Component is not installed.
13E100	This function is not yet supported by the control unit.
13E200	The lower limit value of component B28/8 (Differential pressure sensor (DPF)) was dropped below/not reached.
13E300	Component is not installed.
13E400	Component is not installed.
13E700	The OBD limit value for the injector voltage of cylinder 1 has been exceeded.
13E800	The OBD limit value for the injector voltage of cylinder 4 has been exceeded.
13E900	The OBD limit value for the injector voltage of cylinder 2 has been exceeded.

13EA00	The OBD limit value for the injector voltage of cylinder 5 has been exceeded.
13EB00	The OBD limit value for the injector voltage of cylinder 3 has been exceeded.
13EC00	The OBD limit value for the injector voltage of cylinder 6 has been exceeded.
13ED00	Component is not installed.
13EE00	Component is not installed.
13EF00	Component is not installed.
13F000	Component is not installed.
13F100	Continuous control deviation during discharge time of fuel injector of cylinder 1
13F200	Continuous control deviation during discharge time of fuel injector of cylinder 4
13F300	Continuous control deviation during discharge time of fuel injector of cylinder 2
13F400	Continuous control deviation during discharge time of fuel injector of cylinder 5
13F500	Continuous control deviation during discharge time of fuel injector of cylinder 3
13F600	Continuous control deviation during discharge time of fuel injector of cylinder 6
13F700	The OBD limit value for the injector voltage of cylinder 1 has been exceeded.
13F800	The OBD limit value for the injector voltage of cylinder 4 has been exceeded.
13F900	The OBD limit value for the injector voltage of cylinder 2 has been exceeded.
13FA00	The OBD limit value for the injector voltage of cylinder 5 has been exceeded.
13FB00	The OBD limit value for the injector voltage of cylinder 3 has been exceeded.
13FC00	The OBD limit value for the injector voltage of cylinder 6 has been exceeded.
13FD00	The fuel injector of cylinder 1 has a short circuit.
13FE00	The fuel injector of cylinder 4 has a short circuit.
13FF00	The fuel injector of cylinder 2 has a short circuit.
140000	The fuel injector of cylinder 5 has a short circuit.
140100	The fuel injector of cylinder 3 has a short circuit.
140200	The fuel injector of cylinder 6 has a short circuit.
140500	Component is not installed.
140800	The oxygen concentration in partial load operation is implausible (too high).
140900	Component is not installed.
140C00	The oxygen concentration in full-load operation is implausible (too low).
140D00	Component is not installed.
141000	The oxygen concentration in deceleration mode is implausible (too low).
141100	Component is not installed.
141400	The oxygen concentration in partial load operation is implausible (too low).
141600	Exhaust gas recirculation was shut off due to the malfunction of one of the hot film mass air flow sensors.
141800	Control module has an internal error.
141900	Control module has an internal error.
141A00	Control module has an internal error.
141B00	Control module has an internal error.
141C00	Control module has an internal error.
141D00	Control module has an internal error.
141E00	Control module has an internal error.

141F00	Control module has an internal error.
142000	Control module has an internal error.
142100	Control module has an internal error.
142200	The rail pressure is implausible.
142300	The oxygen concentration in full-load operation is implausible (too high).
142400	Component is not installed.
142700	The oxygen concentration in deceleration mode is implausible (too high).
142800	Component is not installed.
142B00	The ash content of the diesel particulate filter is too high.
142C00	The ash content of the diesel particulate filter has exceeded the warning threshold.
142E00	Internal error: data record faulty
142F00	Internal error: data record faulty
143100	Control module has an internal error.
143200	A frontal impact was detected.
143300	The check signal from control unit Airbag is implausible.
143400	A shortcut was detected at pin 1 of circuit 87.
143500	The voltage supply of circuit 87 has overvoltage.
143600	The voltage supply of circuit 87 has undervoltage.
143700	A shortcut was detected at pin 2 of circuit 87.
143800	The voltage supply of circuit 87 has overvoltage.
143900	The voltage supply of circuit 87 has undervoltage.
143A00	Component A1e16 (Preglow indicator lamp) is defective.
143F00	Component B19/9 (Temperature sensor upstream of diesel particulate filter) has an open circuit.
144000	Component B19/9 (Temperature sensor upstream of diesel particulate filter) has an open circuit.
144100	Component is not installed.
144200	Component B19/11 (Temperature sensor upstream of turbocharger) has an open circuit.
144300	Component B19/11 (Temperature sensor upstream of turbocharger) has an open circuit.
144400	Component is not installed.
144500	Component B19/11 (Temperature sensor upstream of turbocharger) has a plausibility error.
144600	Component B19/11 (Temperature sensor upstream of turbocharger) has a plausibility error.
144700	Component is not installed.
144800	Control module has an internal error.
144900	Control module has an internal error.
144A00	Control module has an internal error.
144B00	Control module has an internal error.
144C00	Control module has an internal error.
144D00	Control module has an internal error.

144E00	Control module has an internal error.
144F00	Control module has an internal error.
145000	Control module has an internal error.
145100	The control unit is overheated.
145200	This function is not yet supported by the control unit.
145300	There is an internal control unit fault in the digital/digital converter.
145400	There is an internal control unit fault in the digital/digital converter.
145700	One of the exhaust gas temperature sensors has overtemperature.
145A00	Component is not installed.
145B00	No LIN message was received from component PremAir sensor.
145D00	Component M16/6 (Throttle valve actuator) has a plausibility error.
145E00	The positive control deviation during throttle valve control is too high.
145F00	The negative control deviation during throttle valve control is too high.
146100	Control deviation is too large.
146200	Control deviation is too large.
146300	Component R48 (Two-disk thermostat heating element) has an open circuit.
146400	Component R48 (Two-disk thermostat heating element) has a short circuit to positive.
146500	Component R48 (Two-disk thermostat heating element) has a short circuit to ground.
146600	Component M13/7 (Transmission oil cooler circulation pump) has an open circuit.
146700	Component M13/7 (Transmission oil cooler circulation pump) has excess temperature.
146800	Component M13/7 (Transmission oil cooler circulation pump) has a short circuit to positive.
146900	Component M13/7 (Transmission oil cooler circulation pump) has a short circuit to ground.
146A00	Internal control module error
146B00	Internal control module error
146C00	Internal control module error
146D00	Component NOx sensor downstream of SCR catalytic converter has a plausibility error.
146E00	This function is not yet supported by the control unit.
146F00	This function is not yet supported by the control unit.
147000	This function is not yet supported by the control unit.
147100	This function is not yet supported by the control unit.
147200	The upper limit value of component NOx sensor downstream of SCR catalytic converter has been exceeded.
147300	The lower limit value of component NOx sensor downstream of SCR catalytic converter was dropped below/not reached.
147400	The upper limit value of component NOx sensor downstream of SCR catalytic converter has been exceeded.
147500	The lower limit value of component NOx sensor downstream of SCR catalytic converter was dropped below/not reached.
147600	Component NOx sensor downstream of SCR catalytic converter has an open circuit in the wiring.

147700	Component NOx sensor downstream of SCR catalytic converter has a short circuit.
147800	The ash content of the diesel particulate filter is too high.
147900	The pressure differential in the diesel particulate filter is too high.
147B00	Component B16/14 (Exhaust gas recirculation temperature sensor) has a short circuit to positive.
147C00	Component B16/14 (Exhaust gas recirculation temperature sensor) has a short circuit to ground.
147E00	This function is not available at present.
147F00	This function is not available at present.
148000	The upper limit value of component NOx sensor downstream of SCR catalytic converter has been reached.
148100	The lower limit value of component NOx sensor downstream of SCR catalytic converter was dropped below/not reached.
148200	Component NOx sensor downstream of SCR catalytic converter has a plausibility error.
148300	The number of permissible start attempts has been exceeded.
148800	This function is not yet supported by the control unit.
148A00	The number of times regeneration of the diesel particulate filter was performed is too high.
148B00	The negative control deviation of exhaust gas recirculation control is too high.
148C00	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
148D00	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
148E00	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
148F00	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149000	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149100	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149200	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149300	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149400	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149500	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149600	Control module has an internal error.
149700	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149800	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149900	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149A00	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
149B00	This function is not yet supported by the control unit.
149C00	Component NOx sensor upstream of SCR catalytic converter is not operational.
149D00	Component NOx sensor downstream of SCR catalytic converter is not operational.
149E00	This function is not yet supported by the control unit.
14A000	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
14A100	Component 'Y27/9 (Left EGR positioner)' has an internal fault.
14A300	This function is not available at present.
14A600	The positive control deviation of exhaust gas recirculation control is too high.

14A700	The negative control deviation of exhaust gas recirculation control is too high.
14A900	The upper limit value of component B60 (Exhaust back pressure sensor) has been exceeded.
14AA00	The lower limit value of component B60 (Exhaust back pressure sensor) was dropped below/not reached.
14AB00	B19/11 (Temperature sensor upstream of turbocharger)
14AC00	Check component B19/11 (Temperature sensor upstream of turbocharger).
14AD00	This function is not available at present.
14AE00	Component B19/11 (Temperature sensor upstream of turbocharger) is defective.
14AF00	Component is not installed.
14B000	The relative boost pressure exceeds the upper limit value.
14B100	Component Hot film mass air flow sensor has a plausibility error.
14B200	Component Hot film mass air flow sensor has a plausibility error.
14B300	Component Y27/9 (Exhaust gas recirculation positioner) is stiff or blocked.
14B400	The control deviation of component Y27/9 (Left EGR positioner) is too high.
14B500	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
14B600	The control deviation of component Y27/9 (Left EGR positioner) is too high.
14B700	This function is not yet supported by the control unit.
14B800	The control deviation of component Y27/9 (Left EGR positioner) is too high.
14B900	This function is not yet supported by the control unit.
14BA00	This function is not yet supported by the control unit.
14BB00	This function is not yet supported by the control unit.
14BC00	This function is not yet supported by the control unit.
14BD00	This function is not yet supported by the control unit.
14BE00	This function is not yet supported by the control unit.
14BF00	This function is not yet supported by the control unit.
14C000	This function is not yet supported by the control unit.
14C100	This function is not yet supported by the control unit.
14C200	This function is not yet supported by the control unit.
14C300	This function is not yet supported by the control unit.
14C400	This function is not yet supported by the control unit.
14C500	This function is not yet supported by the control unit.
14C600	This function is not yet supported by the control unit.
14C700	This function is not yet supported by the control unit.
14C800	This function is not yet supported by the control unit.
14C900	This function is not yet supported by the control unit.
14CA00	This function is not yet supported by the control unit.
14CB00	This function is not yet supported by the control unit.
14CC00	This function is not yet supported by the control unit.
14CD00	This function is not yet supported by the control unit.
14CE00	This function is not yet supported by the control unit.
14CF00	The positive control deviation of exhaust gas recirculation control is too high.

14D000	This function is not yet supported by the control unit.
14D100	This function is not yet supported by the control unit.
14D200	This function is not yet supported by the control unit.
14D300	This function is not yet supported by the control unit.
14D400	This function is not yet supported by the control unit.
14D500	This function is not yet supported by the control unit.
14D600	The signal line of oxygen sensor 1 (cylinder bank 1) and the electric heater circuit have a short circuit to each other.
14D700	The battery voltage is too high.
14D800	Battery voltage is too low.
14D900	The reference voltage connection of oxygen sensor 1 (cylinder bank 1) has an electrical fault or open circuit.
14DA00	Component is not installed.
14DB00	The pump current connection of oxygen sensor 1 (cylinder bank 1) has an electrical fault or open circuit.
14DC00	Component is not installed.
14DD00	The signal return line connection of oxygen sensor 1 (cylinder bank 1) has an electrical fault or open circuit.
14DE00	Component is not installed.
14DF00	The output for the heater of oxygen sensor 1 (cylinder bank 1) has a short circuit to positive.
14E000	The output for the heater of oxygen sensor 1 (cylinder bank 1) has a short circuit to ground.
14E100	The heater for oxygen sensor 1 (cylinder bank 1) has an electrical fault.
14E200	Component is not installed.
14E300	The output for the heater of oxygen sensor 1 (cylinder bank 1) has an electrical fault or open circuit.
14E400	Oxygen sensor 1 (cylinder bank 1) has a malfunction.
14E500	Oxygen sensor 1 (cylinder bank 1) has a malfunction.
14E600	The processor of the oxygen sensor (cylinder bank 1) in the control unit has a malfunction.
14E700	Oxygen sensor 1 (cylinder bank 1) has a short circuit to positive.
14E800	Oxygen sensor 1 (cylinder bank 1) has a short circuit to ground.
14E900	The heater for oxygen sensor 1 (cylinder bank 1) has an electrical fault.
14EA00	The heater for oxygen sensor 1 (cylinder bank 1) has an electrical fault.
14EB00	Rich/lean switchover of oxygen sensor 1 (cylinder bank 1) too slow.
14EC00	This function is not yet supported by the control unit.
14ED00	Component is not installed.
14EE00	This function is not yet supported by the control unit.
14EF00	The processor of the oxygen sensor (cylinder bank 1) in the control unit has a malfunction.
14F000	The signal from oxygen sensor 1 (cylinder bank 1) is shifted towards 'Lean'.
14F100	The signal from oxygen sensor 1 (cylinder bank 1) is shifted towards 'Lean'.
14F200	The signal from oxygen sensor 1 (cylinder bank 1) is shifted towards 'Lean'.



14F300	The signal from oxygen sensor 1 (cylinder bank 1) is shifted towards 'Rich'.
14F400	The signal from oxygen sensor 1 (cylinder bank 1) is shifted towards 'Rich'.
14F500	The signal from oxygen sensor 1 (cylinder bank 1) is shifted towards 'Rich'.
14F600	Oxygen sensor 1 (cylinder bank 1) has a malfunction.
14F700	Component is not installed.
14F800	This function is not yet supported by the control unit.
14F900	Component is not installed.
14FA00	The processor of the oxygen sensor (cylinder bank 1) in the control unit has a malfunction.
14FB00	The processor of the oxygen sensor (cylinder bank 1) in the control unit has a malfunction.
14FC00	Oxygen sensor 1 (cylinder bank 1) has a malfunction.
14FD00	Component is not installed.
14FE00	Oxygen sensor 1 (cylinder bank 1) has a malfunction.
14FF00	Component is not installed.
150000	Oxygen sensor 1 (cylinder bank 1) has an electrical fault.
150100	The upper limit value of component HFM-SFI has been exceeded.
150200	The upper limit value of component HFM-SFI has been exceeded.
150300	The upper limit value of component HFM-SFI has been exceeded.
150400	The processor of the oxygen sensor (cylinder bank 1) in the control unit has a malfunction.
150500	This function is not available at present.
150800	The upper limit value of component NOx sensor downstream of SCR catalytic converter has been exceeded.
150900	The lower limit value of component NOx sensor downstream of SCR catalytic converter was dropped below/not reached.
150A00	The upper limit value of component NOx sensor downstream of SCR catalytic converter has been exceeded.
150B00	The lower limit value of component NOx sensor downstream of SCR catalytic converter was dropped below/not reached.
150C00	This function is not available at present.
150D00	Component B19 (TWC temperature sensor) has a short circuit to positive.
150E00	Component B19 (TWC temperature sensor) has a short circuit to ground.
150F00	This function is not available at present.
151000	This function is not available at present.
151100	This function is not available at present.
151200	This function is not available at present.
151300	This function is not available at present.
151400	This function is not available at present.
151500	Component Y85 (Exhaust gas recirculation cooler bypass switchover valve) has excess temperature.
151600	This function is not yet supported by the control unit.
151700	This function is not yet supported by the control unit.

151800	This function is not yet supported by the control unit.
151C00	This function is not available at present.
151D00	This function is not yet supported by the control unit.
151E00	Component is not installed.
151F00	The throttle valve is blocked due to ice.
152000	This function is not available at present.
152100	This function is not available at present.
152200	This function is not yet supported by the control unit.
152300	This function is not yet supported by the control unit.
152500	Control module has an internal error.
152600	Control module has an internal error.
152700	Control module has an internal error.
152800	Control module has an internal error.
152900	Control module has an internal error.
152A00	Component M4/7 (Engine and AC electric suction fan with integrated control) has a malfunction.
152B00	Component M4/7 (Engine and AC electric suction fan with integrated control) has a malfunction.
152C00	Component M4/7 (Engine and AC electric suction fan with integrated control) has a malfunction.
152D00	Component M4/7 (Engine and AC electric suction fan with integrated control) has a malfunction.
153000	The metered quantity of AdBlue is too low.
153100	The NOx concentration downstream of the SCR catalytic converter is too high.
153400	This function is not yet supported by the control unit.
153500	Component NOx sensor upstream of SCR catalytic converter has a plausibility error.
153600	Component 'NOx sensor upstream of SCR catalytic converter' has an internal fault.
153700	The limit value of component NOx sensor downstream of SCR catalytic converter is exceeded due to offset drift.
153800	Internal fault in component NOx sensor downstream of SCR catalytic converter:
153B00	Component NOx sensor downstream of SCR catalytic converter has a plausibility error.
153C00	Component NOx sensor downstream of SCR catalytic converter has a plausibility error.
154000	Control module has an internal error.
154100	This function is not yet supported by the control unit.
154300	This function is not yet supported by the control unit.
154400	This function is not yet supported by the control unit.
154500	This function is not yet supported by the control unit.
154600	This function is not yet supported by the control unit.
154700	The request for fan output is implausible.
154800	This function is not yet supported by the control unit.
154900	This function is not yet supported by the control unit.

154A00	This function is not yet supported by the control unit.
154B00	This function is not yet supported by the control unit.
154C00	This function is not yet supported by the control unit.
154D00	This function is not yet supported by the control unit.
154E00	This function is not yet supported by the control unit.
154F00	This function is not yet supported by the control unit.
155000	This function is not yet supported by the control unit.
155100	This function is not yet supported by the control unit.
155200	This function is not yet supported by the control unit.
155300	This function is not yet supported by the control unit.
155400	This function is not yet supported by the control unit.
155500	Control module has an internal error.
155600	This function is not yet supported by the control unit.
155700	This function is not yet supported by the control unit.
155A00	This function is not yet supported by the control unit.
155B00	This function is not yet supported by the control unit.
155C00	The engine off time is implausible.
155D00	Exhaust gas recirculation positioner --- Temporary fault
Event 100000	One or more signals sent from control unit Air conditioning via the CAN bus is implausible.
Event 100100	CAN signal 'Torque request' from control unit Air conditioning is implausible.
Event 102200	No CAN message was received from control unit N118/5 (AdBlue® control unit).
Event 102300	CAN signal 'Torque request' from control unit Distronic is implausible.
Event 102400	One or more signals sent from control unit Distronic via the CAN bus is implausible.
Event 102A00	One or more signals sent from control unit Airbag via the CAN bus is implausible.
Event 103000	One or more signals sent from control unit N118/5 (AdBlue® control unit) via the CAN bus is implausible.
Event 103600	One or more messages sent from control unit N47-5 (ESP control unit) via the CAN bus is implausible.
Event 103700	CAN signal 'Stop lamp' from control unit N47-5 (ESP control unit) is implausible.
Event 103A00	CAN controller: CAN bus OFF
Event 103B00	CAN controller: CAN bus OFF
Event 103C00	CAN controller: CAN bus OFF
Event 104000	No CAN message was received from control unit N93 (Central gateway control unit).
Event 105400	The request for fan output is implausible.
Event 105900	One or more signals sent from control unit N47-5 (ESP control unit) via the CAN bus is implausible.
Event 105A00	One or more signals sent from control unit N73 (EIS [EZS] control unit) via the CAN bus is implausible.

Event 105B00 No CAN message was received from control unit N73 (EIS [EZS] control unit).
Event 105C00 CAN signal 'Torque request' from control unit N47-5 (ESP control unit) is implausible.
Event 105D00 One or more signals sent from control unit N47-5 (ESP control unit) via the CAN bus is implausible.
Event 106500 Efficiency of SCR catalytic converter
Event 106800 One or more signals sent from control unit N118/5 (AdBlue® control unit) via the CAN bus is implausible.
Event 109B00 Control unit N3/9 (CDI control unit) has received no LIN message from component G2 (generator).
Event 10BB00 One or more signals sent from control unit Air conditioning via the CAN bus is implausible.
Event 10BC00 No CAN message was received from control unit N22 (AAC [KLA] control and operating unit).
Event 10BD00 No CAN message was received from control unit A1 (Instrument cluster).
Event 10F000 One or more signals sent from control unit N118/5 (AdBlue® control unit) via the CAN bus is implausible.
Event 11AE00 One or more signals sent from control unit Vehicle power supply control module via the CAN bus is implausible.
Event 11C800 One or more signals sent from control unit N47-5 (ESP control unit) via the CAN bus is implausible.
Event 11C900 No CAN message was received from control unit N47-5 (ESP control unit).
Event 11CB00 One or more signals sent from control unit N80 (Steering column module) via the CAN bus is implausible.
Event 11CC00 No CAN message was received from control unit N80 (Steering column module).
Event 11CE00 One or more signals sent from control unit N51 (AIRmatic control unit) via the CAN bus is implausible.
Event 11CF00 No CAN message was received from control unit N51 (AIRmatic control unit).
Event 11E500 An internal control unit reset was performed.
Event 11FD00 One or more signals sent from control unit N15/3 (ETC [EGS] control unit) via the CAN bus is implausible.
Event 11FE00 CAN signal 'Torque request' from control unit N15/3 (ETC [EGS] control unit) is implausible.
Event 11FF00 One or more signals sent from control unit N15/3 (Electronic transmission control control unit) via the CAN bus is implausible.
Event 121800 CAN signal 'Wheel speed' from control unit N47-5 (ESP control unit) is implausible.
Event 121900 CAN signal 'Wheel speed' from control unit N47-5 (ESP control unit) is implausible.
Event 121A00 No CAN message was received from control unit A80 (Intelligent servo module for DIRECT SELECT).
Event 121B00 One or more signals sent from control unit A1 (Instrument cluster) via the CAN bus is implausible.
Event 121E00 The engine off time has an implausible value.

Event 121F00 Control module has an internal error.
Event 122000 CAN signal 'Ambient temperature' from control unit N22/7 (Automatic air conditioning control and operating unit) is implausible.
Event 122100 One or more signals sent from control unit Electric parking brake via the CAN bus is implausible.
Event 122200 No CAN message was received from control unit Electric parking brake.
Event 124900 No CAN message was received from control unit N15/3 (ETC [EGS] control unit).
Event 124A00 One or more signals sent from control unit A80 (Intelligent servo module for DIRECT SELECT) via the CAN bus is implausible.
Event 125100 CAN signal 'Ambient temperature' from control unit N22/7 (Comfort AAC pushbutton control module) is implausible.
Event 125400 CAN signal 'Ambient temperature' from control unit N22/7 (Comfort AAC pushbutton control module) is implausible.
Event 125900 The idle speed increase was approved (active request).
Event 125B00 The idle speed increase was approved (passive request).
Event 129B00 No LIN message was received from component N14/3 (Glow output stage).
Event 129C00 Transmission control (fault 1)
Event 129D00 Transmission control (fault 10)
Event 129E00 Transmission control (fault 11)
Event 129F00 Transmission control (fault 12)
Event 12A000 Transmission control (fault 13)
Event 12A100 Transmission control (fault 14)
Event 12A200 Transmission control (fault 15)
Event 12A300 Transmission control (fault 16)
Event 12A400 Transmission control (fault 17)
Event 12A500 Transmission control (fault 18)
Event 12A600 Transmission control (fault 19)
Event 12A700 Transmission control (fault 2)
Event 12A800 Transmission control (fault 20)
Event 12A900 Transmission control (fault 21)
Event 12AA00 Transmission control (fault 22)
Event 12AB00 Transmission control (fault 23)
Event 12AC00 Transmission control (fault 24)
Event 12AD00 Transmission control (fault 25)
Event 12AE00 Transmission control (fault 26)
Event 12AF00 Transmission control (fault 27)
Event 12B000 Transmission control (fault 28)
Event 12B100 Transmission control (fault 29)
Event 12B200 Transmission control (fault 3)
Event 12B300 Transmission control (fault 30)
Event 12B400 Transmission control (fault 31)
Event 12B500 Transmission control (fault 32)

Event 12B600	Transmission control (fault 4)
Event 12B700	Transmission control (fault 5)
Event 12B800	Transmission control (fault 6)
Event 12B900	Transmission control (fault 7)
Event 12BA00	Transmission control (fault 8)
Event 12BB00	Transmission control (fault 9)
Event 12BF00	This function is not yet supported by the control unit.
Event 134300	No CAN message was received from control unit N118/5 (AdBlue® control unit).
Event 143B00	CAN signal 'Fuel level' from control unit A1 (Instrument cluster) is implausible.
Event 145800	No CAN message was received from control unit N118 (Fuel pump control module).
Event 145900	No CAN message was received from control unit N82 (Battery control module).
Event 145C00	Control unit N47-5 (ESP control unit) requests reduced fan output due to undervoltage.
Event 146000	One or more signals sent from control unit N118/5 (AdBlue® control unit) via the CAN bus is implausible.
Event 147A00	One or more signals sent from control unit N118/5 (AdBlue® control unit) via the CAN bus is implausible.
Event 152400	This function is not yet supported by the control unit.
Event 153900	Efficiency of SCR catalytic converter : Effect is insufficient.
Event 153A00	Efficiency of SCR catalytic converter : Effect is insufficient.
Event 154200	No CAN message was received from control unit N73 (EIS [EZS] control unit).

**Filename:** C:\Program  
Files\Mercedes-Benz\DAS\bin\..\trees\pkw\motordie\CDI6BIN5\menues\MNFCLIST.S

**Cell co-ordinate:** 3 , 3