

Required Service Work <input checked="" type="checkbox"/> Performed (check if performed)	miles (thousands) years	2	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	Not OK ↓	
			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15		
<input type="checkbox"/> Reset maintenance service indicator in instrument cluster			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP00.20-P-0043J
<input type="checkbox"/> Replace engine oil and filter																			
Engine 177			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP18.00-P-0101DD
Engine 274.920 except CODE M005 (4MATIC)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP18.00-P-0101CWI
Engine 274.920 with CODE M005 (4MATIC)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP18.00-P-0101CWE
Engine 276			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP18.00-P-0101CWZ
Engine 256			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP18.00-P-0101MRT
<input type="checkbox"/> Clean visible area of water deflector			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
<input type="checkbox"/> Replace activated charcoal combination filter				•		•		•		•		•		•		•			AP83.00-P-8384B
<i>i</i> Behind glovebox				•		•		•		•		•		•		•			
<input type="checkbox"/> Replace dust filter				•		•		•		•		•		•		•			AP83.00-P-8381C
<i>i</i> Behind plastic cowl in engine compartment				•		•		•		•		•		•		•			
<input type="checkbox"/> Replace brake fluid				•		•		•		•		•		•		•			AP42.00-P-4280C
<i>i</i> Every 2 years				•		•		•		•		•		•		•			
<input type="checkbox"/> Perform brake test				•		•		•		•		•		•		•			<input type="checkbox"/> AP42.00-P-4290BA
<input type="checkbox"/> Check brake fluid level, correct if necessary			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP42.10-P-4210B
<input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP42.10-P-4252E
<input type="checkbox"/> Check and correct all tire air pressures, including spare where applicable			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP40.15-P-4061A
<input type="checkbox"/> Check coolant level and correct if necessary																			
<i>i</i> Observe correct coolant composition																			
Low-temperature circuit (engine 177)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP20.30-P-2052F
Low-temperature circuit (engine 276)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP20.30-P-2052H
Low-temperature circuit (engine 256.9)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP20.30-P-2052K
Main circuit			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP20.30-P-2050F
<input type="checkbox"/> Check windshield washer system fluid, correct if necessary			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP82.35-P-8210C
<input type="checkbox"/> Check engine compartment air flap			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP20.00-P-2052D
Engine 177			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
<input type="checkbox"/> Check catch, safety catch, and hinges on engine hood for proper operation			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/>
<input type="checkbox"/> Check first aid kit			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP68.00-P-6850EW
<input type="checkbox"/> Check underside of vehicle for damage and leaks				•		•		•		•		•		•		•			<input type="checkbox"/> AP00.20-P-0054I
<input type="checkbox"/> Check visible parts in engine compartment for damage and leaks				•		•		•		•		•		•		•			<input type="checkbox"/> AP00.20-P-0055E
<input type="checkbox"/> Check front axle and front axle ball joints, check rubber boots				•		•		•		•		•		•		•			<input type="checkbox"/> AP33.10-P-3358A
<input type="checkbox"/> Check condition of steering and tie rods				•		•		•		•		•		•		•			<input type="checkbox"/> AP46.00-P-4651A
<input type="checkbox"/> Check rear axle and rear axle ball joints, check rubber boots				•		•		•		•		•		•		•			<input type="checkbox"/> AP35.20-P-3552A
<input type="checkbox"/> Check driveshaft flexible couplings				•		•		•		•		•		•		•			<input type="checkbox"/> AP41.10-P-4152EW
<input type="checkbox"/> Check condition of suspension struts or shock absorbers and springs				•		•		•		•		•		•		•			<input type="checkbox"/> AP32.25-P-3255A
<input type="checkbox"/> Check condition of poly-V-belt																			
Engine 177, 276																			
Engine 177				•		•		•		•		•		•		•			<input type="checkbox"/> AP13.22-P-1352D
Engine 276				•		•		•		•		•		•		•			<input type="checkbox"/> AP13.22-P-1352EW
<input type="checkbox"/> Reset maintenance service indicator in instrument cluster			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	AP00.20-P-0043J
<i>i</i> Reminder - if not yet performed			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Required Additional Work																			
<input checked="" type="checkbox"/> Performed (check if performed)																			Not OK ↓
<input type="checkbox"/> Replace rear axle differential oil																			
With CODE 467 (Electronic locking differential) or CODE 471 (Manual locking differential)																			
With CODE 471 (Manual locking differential)					•			•		•		•		•		•			AP35.00-P-3501CMG

Required Additional Work	miles (thousands) years	2	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	Not OK ↓	
<input checked="" type="checkbox"/> Performed (check if performed)																			
With CODE 467 (Electronic locking differential)					•			•			•			•			•		AP35.00-P-3501D
<input type="checkbox"/> Replace engine air filter Engine 177					•			•			•			•			•		AP09.10-P-0980K
<input type="checkbox"/> Replace engine air filter Engine 256.9, 274, 276 Engine 274 Engine 276 Engine 256.9								•									•		AP09.10-P-0980CWF AP09.10-P-0980E AP09.10-P-0980L
<input type="checkbox"/> Replace spark plugs Engine 177 Engine 274 Engine 276 Engine 256.9								•									•		AP15.10-P-1580C AP15.10-P-1580CWF AP15.10-P-1580D AP15.10-P-1580E
<input type="checkbox"/> Replace transfer case oil Engine 177, 256 Transmission 725.09 with CODE M005 (4MATIC) Transmission 725.041/045 with CODE M005 (4MATIC)								•									•		AP28.00-P-2801B AP28.00-P-2801C
<input type="checkbox"/> Replace transfer case oil Engine 274, 276 Transmission 725.0 (except 725.09) with CODE M005 (4MATIC)									•								•		AP28.00-P-2801A
<input type="checkbox"/> Replace automatic transmission oil and filter Engine 177 With transmission 725.09					•			•									•		AP27.00-P-2702B
<input type="checkbox"/> Replace automatic transmission oil and filter Engine 256.9, 274, 276 With transmission 725.04 With transmission 725.01								•									•		AP27.00-P-2702B AP27.00-P-2702BE
<input type="checkbox"/> Replace fuel filter																	•		AP47.20-P-0780D
<input type="checkbox"/> Replace main circuit coolant <input checked="" type="checkbox"/> Observe correct coolant composition																	•		AP20.00-P-2082G
<input type="checkbox"/> Replace low-temperature circuit coolant <input checked="" type="checkbox"/> Observe correct coolant composition Engine 177 Engine 276.8 Engine 256.9																	•		AP20.00-P-2083C AP20.00-P-2083I AP20.00-P-2083D
Recommended Service Work	miles (thousands) years	2	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	Not OK ↓	
<input checked="" type="checkbox"/> Performed (check if performed)																			
<input type="checkbox"/> Replace wiper blades			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/>
<input type="checkbox"/> Check windshield wiper, washer and headlamp washer system operation			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP82.35-P-8252D
<input type="checkbox"/> Inspect tires for damage, measure tread depth and enter table at the end of the service sheet			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP40.10-P-4051EW
<input type="checkbox"/> Tire rotation (where applicable)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
<input type="checkbox"/> Activate Tire Pressure Monitoring System <input checked="" type="checkbox"/> Refer to vehicle Operator's Manual			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
<input type="checkbox"/> Check TIREFIT tire sealant expiration date (where applicable)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP40.10-P-4054R
<input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed Pads Discs Discs, with CODE B07 (Ceramic brake system)			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP42.10-P-4252E <input type="checkbox"/> AP42.10-P-4256EW <input type="checkbox"/> AP42.10-P-4258-02RQ
<input type="checkbox"/> Check brake system components, lines, hoses, calipers			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/>

Recommended Service Work <input checked="" type="checkbox"/> Performed (check if performed)	miles (thousands) years	2	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	Not OK ↓
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15		
<input type="checkbox"/> Check headlamp setting, correct if necessary			•		•		•		•		•		•		•		•	<input type="checkbox"/> AP82.10-P-8260J
<input type="checkbox"/> Check operation of headlamp range adjustment			•		•		•		•		•		•		•		•	<input type="checkbox"/> AP82.10-P-8250EW
<input type="checkbox"/> Check all exterior lights		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP82.10-P-8252EW
<input type="checkbox"/> Check warning/indicator lamps		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP54.30-P-5451HA
<input type="checkbox"/> Check illumination and interior lighting		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP54.30-P-5453E
<input type="checkbox"/> Check trunk / cargo area lights		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/>
<input type="checkbox"/> Replace battery for KEYLESS-GO key With KEYLESS-GO function <input checked="" type="checkbox"/> After consultation with customer		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
<input type="checkbox"/> Check, clean and lubricate Panoramic sliding roof guide mechanism With CODE 413 (Automatic panoramic sliding sunroof)			•		•		•		•		•		•		•		•	AP77.20-P-7732A
<input type="checkbox"/> Check horn		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/>
<input type="checkbox"/> Check battery condition. Attach printout to sheet			•		•		•		•		•		•		•		•	AP54.10-P-5449U
<input type="checkbox"/> Check chassis and load bearing body components for damage and corrosion		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/>
<input type="checkbox"/> Check ex-factory driving aids (where applicable)		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	<input type="checkbox"/> AP86.20-P-8649U
<input type="checkbox"/> Check seatbelts and buckles for proper operation or damage			•		•		•		•		•		•		•		•	<input type="checkbox"/>
<input type="checkbox"/> Check for body paint damage			•		•		•		•		•		•		•		•	<input type="checkbox"/> AP60.00-P-0050I
<input type="checkbox"/> Check condition and operation of trailer hitch With CODE 550 (Trailer coupling)			•		•		•		•		•		•		•		•	<input type="checkbox"/> AP31.11-P-3152A

High Mileage Required Service Work at 160,000 miles or 16 years; then every 20,000 miles or 2 years																		
<input checked="" type="checkbox"/> Plus any applicable additional work listed at the end of the service sheet																		
<input checked="" type="checkbox"/> Performed (check if performed)																		Not OK ↓
	<input type="checkbox"/> Reset maintenance service indicator in instrument cluster																	
<input type="checkbox"/> Replace engine oil and filter Engine 177 Engine 274.920 except CODE M005 (4MATIC) Engine 274.920 with CODE M005 (4MATIC) Engine 276 Engine 256																		AP18.00-P-0101DD AP18.00-P-0101CW1 AP18.00-P-0101CWE AP18.00-P-0101CWZ AP18.00-P-0101MRT
<input type="checkbox"/> Clean visible area of water deflector																		
<input type="checkbox"/> Replace activated charcoal combination filter <input checked="" type="checkbox"/> Behind glovebox																		AP83.00-P-8384B
<input type="checkbox"/> Replace dust filter <input checked="" type="checkbox"/> Behind plastic cowl in engine compartment																		AP83.00-P-8381C
<input type="checkbox"/> Replace brake fluid <input checked="" type="checkbox"/> Every 2 years																		AP42.00-P-4280C
<input type="checkbox"/> Perform brake test																		<input type="checkbox"/> AP42.00-P-4290BA
<input type="checkbox"/> Check brake fluid level, correct if necessary																		<input type="checkbox"/> AP42.10-P-4210B
<input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed																		<input type="checkbox"/> AP42.10-P-4252E
<input type="checkbox"/> Check and correct all tire air pressures, including spare where applicable																		AP40.15-P-4061A
<input type="checkbox"/> Check coolant level and correct if necessary <input checked="" type="checkbox"/> Observe correct coolant composition Low-temperature circuit (engine 177) Low-temperature circuit (engine 276) Low-temperature circuit (engine 256.9) Main circuit																		<input type="checkbox"/> AP20.30-P-2052F <input type="checkbox"/> AP20.30-P-2052H <input type="checkbox"/> AP20.30-P-2052K <input type="checkbox"/> AP20.30-P-2050F
<input type="checkbox"/> Check windshield washer system fluid, correct if necessary																		<input type="checkbox"/> AP82.35-P-8210C
<input type="checkbox"/> Check engine compartment air flap Engine 177																		AP20.00-P-2052D

<input type="checkbox"/> Check catch, safety catch, and hinges on engine hood for proper operation	<input type="checkbox"/>	
<input type="checkbox"/> Check first aid kit	<input type="checkbox"/>	AP68.00-P-6850EW
<input type="checkbox"/> Check underside of vehicle for damage and leaks	<input type="checkbox"/>	AP00.20-P-0054I
<input type="checkbox"/> Check visible parts in engine compartment for damage and leaks	<input type="checkbox"/>	AP00.20-P-0055E
<input type="checkbox"/> Check front axle and front axle ball joints, check rubber boots	<input type="checkbox"/>	AP33.10-P-3358A
<input type="checkbox"/> Check condition of steering and tie rods	<input type="checkbox"/>	AP46.00-P-4651A
<input type="checkbox"/> Check rear axle and rear axle ball joints, check rubber boots	<input type="checkbox"/>	AP35.20-P-3552A
<input type="checkbox"/> Check driveshaft flexible couplings	<input type="checkbox"/>	AP41.10-P-4152EW
<input type="checkbox"/> Check condition of suspension struts or shock absorbers and springs	<input type="checkbox"/>	AP32.25-P-3255A
<input type="checkbox"/> Check condition of poly-V-belt Engine 177, 276		
Engine 177	<input type="checkbox"/>	AP13.22-P-1352D
Engine 276	<input type="checkbox"/>	AP13.22-P-1352EW
<input type="checkbox"/> Reset maintenance service indicator in instrument cluster		AP00.20-P-0043J
<input type="checkbox"/> i Reminder - if not yet performed		
High Mileage Recommended Service Work at 160,000 miles or 16 years; then every 20,000 miles or 2 years		
<input type="checkbox"/> i Plus any applicable additional work listed at the end of the service sheet		
<input checked="" type="checkbox"/> Performed (check if performed)		Not OK ↓
<input type="checkbox"/> Replace wiper blades	<input type="checkbox"/>	
<input type="checkbox"/> Check windshield wiper, washer and headlamp washer system operation	<input type="checkbox"/>	AP82.35-P-8252D
<input type="checkbox"/> Inspect tires for damage, measure tread depth and enter table at the end of the service sheet	<input type="checkbox"/>	AP40.10-P-4051EW
<input type="checkbox"/> Tire rotation (where applicable)		
<input type="checkbox"/> Activate Tire Pressure Monitoring System i Refer to vehicle Operator's Manual		
<input type="checkbox"/> Check TIREFIT tire sealant expiration date (where applicable)	<input type="checkbox"/>	AP40.10-P-4054R
<input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed		
Pads	<input type="checkbox"/>	AP42.10-P-4252E
Discs	<input type="checkbox"/>	AP42.10-P-4256EW
Discs, with CODE B07 (Ceramic brake system)	<input type="checkbox"/>	AP42.10-P-4258-02RQ
<input type="checkbox"/> Check brake system components, lines, hoses, calipers	<input type="checkbox"/>	
<input type="checkbox"/> Check headlamp setting, correct if necessary	<input type="checkbox"/>	AP82.10-P-8260J
<input type="checkbox"/> Check operation of headlamp range adjustment	<input type="checkbox"/>	AP82.10-P-8250EW
<input type="checkbox"/> Check all exterior lights	<input type="checkbox"/>	AP82.10-P-8252EW
<input type="checkbox"/> Check warning/indicator lamps	<input type="checkbox"/>	AP54.30-P-5451HA
<input type="checkbox"/> Check illumination and interior lighting	<input type="checkbox"/>	AP54.30-P-5453E
<input type="checkbox"/> Check trunk / cargo area lights	<input type="checkbox"/>	
<input type="checkbox"/> Replace battery for KEYLESS-GO key With KEYLESS-GO function i After consultation with customer		
<input type="checkbox"/> Check, clean and lubricate Panoramic sliding roof guide mechanism With CODE 413 (Automatic panoramic sliding sunroof)		AP77.20-P-7732A
<input type="checkbox"/> Check horn	<input type="checkbox"/>	
<input type="checkbox"/> Check battery condition. Attach printout to sheet		AP54.10-P-5449U
<input type="checkbox"/> Check chassis and load bearing body components for damage and corrosion	<input type="checkbox"/>	
<input type="checkbox"/> Check ex-factory driving aids (where applicable)	<input type="checkbox"/>	AP86.20-P-8649U
<input type="checkbox"/> Check seatbelts and buckles for proper operation or damage	<input type="checkbox"/>	
<input type="checkbox"/> Check for body paint damage	<input type="checkbox"/>	AP60.00-P-0050I

<input type="checkbox"/> Check condition and operation of trailer hitch With CODE 550 (Trailer coupling)	<input type="checkbox"/> AP31.11-P-3152A
High Mileage Required Service Work at 170,000 miles or 17 years; then every 20,000 miles or 2 years	
i Plus any applicable additional work listed at the end of the service sheet	
<input checked="" type="checkbox"/> Performed (check if performed)	Not OK ↓
<input type="checkbox"/> Reset maintenance service indicator in instrument cluster	AP00.20-P-0043J
<input type="checkbox"/> Replace engine oil and filter Engine 177 Engine 274.920 except CODE M005 (4MATIC) Engine 274.920 with CODE M005 (4MATIC) Engine 276 Engine 256	AP18.00-P-0101DD AP18.00-P-0101CWI AP18.00-P-0101CWE AP18.00-P-0101CWZ AP18.00-P-0101MRT
<input type="checkbox"/> Clean visible area of water deflector	
<input type="checkbox"/> Check brake fluid level, correct if necessary	<input type="checkbox"/> AP42.10-P-4210B
<input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed	<input type="checkbox"/> AP42.10-P-4252E
<input type="checkbox"/> Check and correct all tire air pressures, including spare where applicable	AP40.15-P-4061A
<input type="checkbox"/> Check coolant level and correct if necessary i Observe correct coolant composition Low-temperature circuit (engine 177) Low-temperature circuit (engine 276) Low-temperature circuit (engine 256.9) Main circuit	<input type="checkbox"/> AP20.30-P-2052F <input type="checkbox"/> AP20.30-P-2052H <input type="checkbox"/> AP20.30-P-2052K <input type="checkbox"/> AP20.30-P-2050F
<input type="checkbox"/> Check windshield washer system fluid, correct if necessary	<input type="checkbox"/> AP82.35-P-8210C
<input type="checkbox"/> Check engine compartment air flap Engine 177	AP20.00-P-2052D
<input type="checkbox"/> Check catch, safety catch, and hinges on engine hood for proper operation	<input type="checkbox"/>
<input type="checkbox"/> Check first aid kit	<input type="checkbox"/> AP68.00-P-6850EW
<input type="checkbox"/> Reset maintenance service indicator in instrument cluster i Reminder - if not yet performed	AP00.20-P-0043J
High Mileage Recommended Service Work at 170,000 miles or 17 years; then every 20,000 miles or 2 years	
i Plus any applicable additional work listed at the end of the service sheet	
<input checked="" type="checkbox"/> Performed (check if performed)	Not OK ↓
<input type="checkbox"/> Replace wiper blades	<input type="checkbox"/>
<input type="checkbox"/> Check windshield wiper, washer and headlamp washer system operation	<input type="checkbox"/> AP82.35-P-8252D
<input type="checkbox"/> Inspect tires for damage, measure tread depth and enter table at the end of the service sheet	<input type="checkbox"/> AP40.10-P-4051EW
<input type="checkbox"/> Tire rotation (where applicable)	
<input type="checkbox"/> Activate Tire Pressure Monitoring System i Refer to vehicle Operator's Manual	
<input type="checkbox"/> Check TIREFIT tire sealant expiration date (where applicable)	<input type="checkbox"/> AP40.10-P-4054R
<input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed Pads Discs Discs, with CODE B07 (Ceramic brake system)	<input type="checkbox"/> AP42.10-P-4252E <input type="checkbox"/> AP42.10-P-4256EW <input type="checkbox"/> AP42.10-P-4258-02RQ
<input type="checkbox"/> Check brake system components, lines, hoses, calipers	<input type="checkbox"/>
<input type="checkbox"/> Check all exterior lights	<input type="checkbox"/> AP82.10-P-8252EW
<input type="checkbox"/> Check warning/indicator lamps	<input type="checkbox"/> AP54.30-P-5451HA
<input type="checkbox"/> Check illumination and interior lighting	<input type="checkbox"/> AP54.30-P-5453E
<input type="checkbox"/> Check trunk / cargo area lights	<input type="checkbox"/>

<input type="checkbox"/> Replace battery for KEYLESS-GO key With KEYLESS-GO function i After consultation with customer		
<input type="checkbox"/> Check horn		<input type="checkbox"/>
<input type="checkbox"/> Check chassis and load bearing body components for damage and corrosion		<input type="checkbox"/>
<input type="checkbox"/> Check ex-factory driving aids (where applicable)		<input type="checkbox"/> AP86.20-P-8649U
High Mileage Additional Work		
<input checked="" type="checkbox"/> Performed (check if performed)		
<input type="checkbox"/> Replace rear axle differential oil With CODE 467 (Electronic locking differential) or CODE 471 (Manual locking differential) With CODE 471 (Manual locking differential) With CODE 467 (Electronic locking differential)	If more than 30,000 miles or 3 years since last replacement If more than 30,000 miles or 3 years since last replacement	AP35.00-P-3501CMG AP35.00-P-3501D
<input type="checkbox"/> Replace engine air filter Engine 177	If more than 30,000 miles or 3 years since last replacement	AP09.10-P-0980K
<input type="checkbox"/> Replace engine air filter Engine 256.9, 274, 276 Engine 274 Engine 276 Engine 256.9	If more than 50,000 miles or 5 years since last replacement If more than 50,000 miles or 5 years since last replacement If more than 50,000 miles or 5 years since last replacement	AP09.10-P-0980CWG AP09.10-P-0980E AP09.10-P-0980L
<input type="checkbox"/> Replace spark plugs Engine 177 Engine 274 Engine 276 Engine 256.9	If more than 50,000 miles or 5 years since last replacement If more than 50,000 miles or 5 years since last replacement If more than 50,000 miles or 5 years since last replacement If more than 50,000 miles or 5 years since last replacement	AP15.10-P-1580C AP15.10-P-1580CWF AP15.10-P-1580D AP15.10-P-1580E
<input type="checkbox"/> Replace transfer case oil Engine 177, 256 Transmission 725.09 with CODE M005 (4MATIC) Transmission 725.041/045 with CODE M005 (4MATIC)	If more than 50,000 miles or 5 years since last replacement If more than 50,000 miles or 5 years since last replacement	AP28.00-P-2801B AP28.00-P-2801C
<input type="checkbox"/> Replace transfer case oil Engine 274, 276 Transmission 725.0 (except 725.09) with CODE M005 (4MATIC)	If more than 60,000 miles or 6 years since last replacement	AP28.00-P-2801A
<input type="checkbox"/> Replace automatic transmission oil and filter Engine 177 With transmission 725.09	If more than 30,000 miles or 3 years since last replacement	AP27.00-P-2702B
<input type="checkbox"/> Replace automatic transmission oil and filter Engine 256.9, 274, 276 With transmission 725.04 With transmission 725.01	If more than 60,000 miles or 6 years since last replacement If more than 60,000 miles or 6 years since last replacement	AP27.00-P-2702B AP27.00-P-2702BE
<input type="checkbox"/> Replace fuel filter	If more than 120,000 miles or 12 years since last replacement	AP47.20-P-0780D
<input type="checkbox"/> Replace main circuit coolant i Observe correct coolant composition	If more than 120,000 miles or 12 years since last replacement	AP20.00-P-2082G
<input type="checkbox"/> Replace low-temperature circuit coolant i Observe correct coolant composition Engine 177 Engine 276.8 Engine 256.9	If more than 120,000 miles or 12 years since last replacement If more than 120,000 miles or 12 years since last replacement If more than 120,000 miles or 12 years since last replacement	AP20.00-P-2083C AP20.00-P-2083I AP20.00-P-2083D

Tire inflation pressure (bar/psi)				
LF	RF	LR	RR	Spare

Tire tread depth (mm)				
	LF	RF	LR	RR
outside				
center				
inside				