

Variant coding

	Coding
Premature termination of seat belt warning	no premature termination
Seat belt warning starts at	Engine on
Language menu	all without Japan
Language variants	Oxford English
United Kingdom variant	disable
NCAP	unavailable
Motor type	Gasoline engine
Handlebars	right
KI can be woken up via MFL buttons	No
Configuration while driving	enable
High beam allowed	enable
AI is programmed buzzer output	a
GWSZ presentation	enable
Reset interval	250 km
Travel computer active	Yes
Image range and tank info	enable
Trip computer display with reserve with	Values
Fuel value in trip calculator available	Yes
Clock in the right display	active
Brake warning	symbol
Seat belt warning available	Yes
Acoustic seat belt warning	Yes
Belt warning display active	No

Key warning present	Yes
Abort of the key warning after 30 s	a
Handbrake warning available	Yes
Light warning active	Yes
Gulf state warning active	No
Light warning autom. Driving lights active	Yes
CHECK-ENGINE display warning active	No
Check engine active	Yes
Configured lamp with motor symbol	Yes
Close center tray warning	disable
4 sec. Airbag warning	passive
Display of speed warning	km / h
VREG vehicle display status line	enable
Evaluate V-Reg signals from	ID 258 (DTR)
ART	available

Tire pressure monitoring active	No
Tire pressure lamp	disable
Distance unit for WIA	miles
Speedometer curve symmetry	unbalanced
K number	K number 1
Auxiliary heating can be operated on KL15R	No
Auxiliary heater active	No
Representation of the background symbol	passive
Consumption display km	l / 100km

Consumption display miles	UK gallons
Evaluate fuel cap information	No
Fuel reserve warning active	No
Tank sender stuck detection	disable
Parking heater available	No
air conditioning	available
Memory package	available
ARMADA	available
ZGW	available
ABC	available
ART-INFO active during lamp test	Yes
Convertible top control unit available	Yes
Emergency call / telematics TLM	passive
Keyless Go available	No
Emergency call / telematics CP	passive
LCT / CP	unavailable
Speedometer curve	Characteristic curve 1
Display speedometer active	Yes
IPS	unavailable
Operator feedback ABC	enable
Distronic display units	meter
Diagnosis via K-Line	enable
Diagnosis via CAN	enable
New services available	No

Diagnosis System	enable	Copyright 1999 Daimler AG
Cancel button	independent of the event mask	
Menu after wake-up	last key	
Check charge control warning FSA bit	disable	
Check charge control warning FSE bit	disable	
Winter tire limit control	new (160-240)	
Terminal 61 - warning	active	
unified gear display	not active	
CVT	unavailable	
NAG	available	
KSG	unavailable	
AMG speed step mode	disable	
Speed condition for warnings	active	
Correction of minimum warning active	Yes	
Correction overfill 1 active	Yes	
Acceleration criterion	active	
Oil underfill warning 2	active	
WIA warning threshold	Warning factor 1.0	
WIA / EA mode	WIA-1	
Remaining time WIA (WIAZ bit)	variable (0)	
Oil quantity unit	liter	
Oil refill detection active	Yes	
WIA activated	Yes	
Oil overfill warning	a	
Oil underfill warning	a	

Oil shortage indicator	a
Time limit	2 years
Display of scope of service	a
Vehicle type	Car
Service sequence	variable
Telephone available with MC-net	No
Telephone available with ext. Ki	Yes
Navigation available with MC-net	No

Navigation available with ext. Ki	Yes
-----------------------------------	-----

Audio available with MC-net	No
-----------------------------	----

Audio available with ext. Ki	Yes
Time synchronization via MC-net	No
Time synchronization via ext. Ki	Yes
Menu 01 interior light	enable
Menu 02 headlights	enable
Menu 03 low beam	enable
Menu 04 speedometer	enable
Menu 05 outside temperature	enable
Menu 06 Fold down mirror when locked	enable
Menu 07 door lock	enable
Menu 08 Vmax limitation	enable
Menu 09 language	enable
Menu 10 audio mode	disable
Menu 11 mirror adjustment	enable
Menu 12 time display 12/24	disable
Menu 13 key dependency	enable
Menu 14 tire pressure unit	disable
Menu 15 IRS	enable
Menu 16 entry / exit aid	enable
Menu 17 trunk lid limitation	disable
Menu 18 ambient lighting	enable
Menu 20 heating	disable
Menu 21 Display unit digital speedometer	enable
Menu 22 clock synchronization manual / head unit	enable

Filename: C:\Program Files (x86)\Mercedes-
Benz\ DAS \ bin \ .. \ trees \ pkw \ flexecu \ flexsa.s
**Cell co-
ordinate:** 3, 2