



Mercedes-Benz

Pre-Delivery Inspection Model Year 2018

213 E-Class

E300

E300-4M

E400-4M

AMG E43

AMG E63

Dealer: _____ Technician: _____ Repair Order: _____

VIN: _____ Stock #: _____ Date: _____

FIT AND APPEARANCE: Where referenced, this refers to checking for dirt, damage, scratches, blemishes, dents, uneven gaps, and poor fit

FUNCTION: Where referenced, this refers to checking for proper operation, good performance, illumination, and quiet, smooth operation (as applicable)

PRIOR TO PDI	OK ✓
Verify that all recalls/service campaigns have been performed	
EXTERIOR INSPECTION	OK ✓
Walk-around	
Exterior protection: Remove protection/ wrap guard before expiration	
Label Verification: Visual Inspection for Monroney (MSRP) Label and Parts Content/SMOG Index Label; For vehicles retailed in the state of N.J., please remove G. Daimler sticker from windshield	
Exterior features: No scratches, blemishes, poor fit (bumper covers, grill, bump strips, mirrors, exterior lights, antennas)	
Window glass: No scratches, chips, cracks, distortion	
SmartKey & Keyless Go: For both keys, function of lock & unlock (at each door)/ trunk release/ panic/ summer open & convenience close (full range of motion windows/ sunroof)	
Wheels and Tires	
Tires: Correct tire pressure (as indicated on fuel tank door); Inspect for damage; Confirm same manufacturer for all tires	
Wheels: Torque wheel bolts to required specifications; Inspect rims for damage	
Trunk / Cargo	
Trunk / Cargo features: Function of trunk illumination/ emergency trunk release/ electronic closing & locking features (incl. tailgate on wagon)	
Tool kit & tirefit: Verify proper installation of vehicle jack/ tool kit/ tire air compressor and tire filler sealant bottle	
Trunk / Cargo contents: Place first aid kit, sunroof crank, head restraint reset tool in appropriate locations, and operator's manual portfolio in glove box / Cargo net	
Under Hood	
Engine bay: Install hood star; Inspect for any leaks or damage; Hose and wire harness routing/ clamps & fasteners/ electrical grounds	
Fluids: Fluid levels (check with engine at operating temperature [engine oil, brake fluid, engine coolant, washer fluid, power steering fluid]); Correct as necessary	
Battery charger: Connect battery charger to under hood jumper terminals for Interior Inspection	
INTERIOR INSPECTION	OK ✓
At All Positions	
Interior protection: Remove interior protective material (except carpet, door sill, and driver seat protection)	
Floor mats: Verify presence and install floor mats	
At Driver Seat Position	
Exterior lights: Function of headlamps (including aim & high beams)/ turn signals/ parking lamps/ fog lamps/ brake lights/ reverse lights/ hazards	
Night View Assist: Function of night view system (Message displayed in instrument cluster)/ Check for dirt in infrared camera lens or glass	
Exterior mirrors: Function of exterior mirror adjustment	
Instrument cluster: Function of gauges/ warning lamps/ display illumination (set to full illumination)	
Steering wheel/column: Function of steering wheel controls and multi-function display (scroll through menus, check settings); Function of horn / Function of steering column / Function of touch control	
Attention Assist: Function of Attention Assist (activate Attention Assist in the multi-function display using steering wheel controls) - Indicator lamp displays	
Door: Check door for noises/operation	
Seat belts: Fit and appearance of seat belts; Function of retraction/ locking/ latching/ height adjustment	
Head restraints: Operation and adjustment of head restraints	
Overhead controls: Function of front & rear interior lamps/ reading lamps/ rear view mirror/ garage door opener buttons (LED illuminates) Sunroof	
Sunroof: Function of sunroof (incl. 1-touch open/close, auto-reverse, & pop-up)/ 1-touch open for glass panel and sunshade (panorama roof only)	
Center console buttons: Function of rear window sunshade button / Controls for multimedia system / Read out the navigation version from COMAND in Navigation view>Options>Map Content>Map Version. If an update is available, install the update on an additional Repair Order line / ECO start/stop / Dynamic select / Raise lower vehicle height	
Reminder messages: Audible beep & message for exterior lights on/ key in ignition; Function of seatbelt telltale lamp	
Locks: Function of all lock and unlock switches	

Seats: Function of seat adjustments/ memory feature/ multi-contour seat adjustments	
Windows: Proper window operation (full range of motion); Auto-reverse function (w/ plastic wedge)	
Door: Check door for noises/operation	
Locks: Central locking & unlocking / Rear window lock / trunk release	
At Rear Seat Position	
Rear seat features: Function of reading lamps; Installation of child seat anchors; Folding rear seats	
Windows: Proper window operation (full range of motion); Auto-reverse function (w/ plastic wedge)	
Seat belts: Fit and appearance of seat belts; Function of retraction/ locking/ latching/ height adjustment	
Head restraints: Operation and adjustment of head restraints	
Door: Check door for noises/operation	
Rear climate control: Function of temperature adjustment/ air distribution & airflow adjustments/ rear air vents; Set to 72° AUTO	
At Passenger Seat Position	
Occupant classification system: Function of passenger seat airbag sensor (sit in seat and observe passenger airbag indicator lamp)	
Window: Proper window operation (full range of motion); Auto-reverse function (w/ plastic wedge)	
Door: Check door for noises/operation	
Seat belts: Fit and appearance of seat belts; Function of retraction/ locking/ latching/ height adjustment	
Head restraints: Operation and adjustment of head restraints	
ROAD TEST	OK ✓
Keyless Go: Check function lock/unlock / Engine starting	
Telematics & Climate Control (outdoor & stationary, engine on)	
Climate control: Function of climate control system (cycle through max cool, max heat, air distribution & airflow adjustments, function of switches)/ front air vents; Set to 72° AUTO / Air balance	
AM & FM radio: Function of AM & FM radio/ seek/ autostore/ manual station selection/ Good reception	
CD player and CD changer: Function of CD playback/ seek/ scan/ direct track and CD entry	
Sound & speakers: Function of volume/ balance/ fade/ bass/ treble/ mute (reset all to normal settings); Function of each speaker (using audio test CD)	
Satellite radio: Reception of satellite radio Traffic and Weather 184 station (ensure clear view of satellites)	
Voice control: Proper recognition/ response to voice commands	
Navigation: Function of map and route guidance (Enter dealer as destination and verify route guidance during test drive)	
Test Drive (3-5 miles)	
Transmission safety lock: Function of safety lock (cannot shift out of park if key off or without foot on brake)	
Rearview/360° camera: Verify camera lens protection is removed; Function of screen display/ reversing guides/ parallel parking guides	
Engine: Start with SmartKey/ Keyless Go; Engine performance (idle quality, throttle operation, power)	
Noises: No unusual noises from body, seats, engine, transmission, suspension, steering, brakes, tires/ wind noises (at varied speeds)	
Parking brake: Function of engagement & release/ warning lamp	
Vibrations: No vibrations from tires, brakes, steering	
Wipers & washers: Function of windshield wipers & washers; Function of headlamp washers	
Parktronic / Park Assist: Function of front & rear distance indicators/ audible warnings/ Parktronic off button	
Drive dynamic seat: Function of adjustment during cornering	
Brakes: Braking power/ pedal feel (not too soft/firm)	
Automatic Transmission: Shift quality (all gears)/ Function C, S & M shift programs/ touch shift/ steering wheel shifters	
Tire pressure monitor: Activate tire pressure monitor	
Exterior lamps: Function of LED headlamp / Active curve illumination / Cornering lights	
Steering: Proper feel/ alignment/ no excessive play	
Suspension: Proper feel & ride quality (normal suspension setting)	
Cruise control/Drive pilot: Function of speed continuation/ touch acceleration & deceleration/ resume/ cancel; Function of Distronic (maintains set distance and appropriate speed/ distance warning) / Steering pilot / Active Lane Change assist	
Head-Up Display: Display function	
Activate mbrace2: Select the globe icon at the top right of COMAND and then select the MB Apps tile.	

MECHANICAL & SYSTEMS INSPECTION	OK ✓
SDS Quick Test: Perform Quick Test and investigate any fault codes; Attach final printed results to RO	
If vehicle won't be delivered for >7 days, activate transport mode and deactivate at time of delivery	
Underbody check: Remove underbody panels; Check drive train/ suspension/ brakes/ rims & tires/ exhaust system for leaks, damages, and proper hydraulic line routing; Reinstall underbody panels	
Lower body work: No scratches, cracks, gaps, poor fit	
mbrace: Print registration data (MIN, MDN) and attach to RO	
SERVICE RECHECK (Must perform within 3 days of delivery)	OK ✓
Technician: _____ Date: _____ Salesperson** : _____ Date: _____ **Salesperson's signature required for spot deliveries	
Verify that all recall/service campaigns have been performed	
Main Battery: Switch on driving lamps for 60 seconds, then perform battery test through instrument cluster; Battery Voltage: _____; If voltage is below 12.4 V perform Midtronics Test and attach printed results to RO; Recharge/replace as directed	
Tire pressure: Check pressure and correct as necessary (reset tire pressure monitor if tire pressure corrected)	
Brakes: Visually inspect brake discs for corrosion and correct as necessary	
Wipers: Install permanent windshield wipers	
Floor mats: Remove carpet protection and install floor mats	
License plate bracket/frame: Install front license plate bracket if required by state law	
Open roof half way: Check roof seals, windows, and pillars for excessive black sealant. Clean	