

MODEL 164

- 1 Armrest cover
- 2 Bolts
- 3 Portable CTEL stowage tray
- 4 Electrical connector
- 5 Plug connections
- 6 Clamp
- 7 Guide lug



P82.70-5454-06

☒ ☒	Remove/install		
1	Unlock armrest cover (1) and set upright		
2	Remove bolts (2)		
3	Unlock stowage tray and set upright		
4	Lift portable CTEL stowage tray (3) (arrow A) and pull forward	i Installation: Pay attention to installation position of guide tab (7).	
5	Turn over portable CTEL stowage tray (3)		
6	Disconnect electrical connector (4)		
7	Unclip connectors (5)		
8	Remove clamp (6)		
9	Install in the reverse order		