

## MODEL 164 with CODE (810) Sound system

N40/3 Amplifier for sound system



P82.62-2730-06




P82.62-2731-09

- 1 Rear floor covering
- 2 Cover
- 3 Anchoring lug cover
- 4 Bolt
- 11 Bolts12 Bracket
- N40/3 Amplifier for sound system
- 5 Anchoring lug
- 6 Clip
- 7 Air duct
- 8 Nuts

9 Left intermediate bottom10 Nuts

N40/3 Amplifier for sound system



## **Modification notes**

26.7.06	Disconnect/connect ground line for battery and carry out	Steps 2 and 18	
	basic programming removed		

XX	Remove/install		
()	Notes on avoiding damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1	Read out coding of amplifier for sound system (N40/3)	Only when replacing amplifier for sound system (N40/3) and when it can still be read out with STAR DIAGNOSIS.	
<b>⊯</b> AD	Connect STAR DIAGNOSIS and read out fault memory		AD00.00-P-2000-04A
		STAR DIAGNOSIS diagnosis system	*WH58.30-Z-1048-13A
2	Remove left front seat		AR91.10-P-1000GZ
3	Remove left front door sill molding		AR68.30-P-4100GZ
4	Remove left rear door sill molding		AR68.30-P-4100GZ
5	Remove B-pillar paneling at bottom left		AR68.30-P-4700GZ
6	Remove cover (2).		
7	Remove anchoring lug cover (3)		
8	Remove bolt (4) and remove anchoring lug (5)	i Installation: Insert anchoring lug with its positioning tab properly aligned.	*BA68.50-P-1001-03F
9	Fold over left rear floor covering (1)		27.00.00 7 700 7 00
10	Remove clip (6) and remove air duct (7)		
11	Remove nuts (8) and remove left intermediate bottom (9)		
12	Disconnect electrical connectors from amplifier for sound system (N40/3)	i Cover fiber optic cable using suitable means.	
13	Remove nuts (10) and remove amplifier for sound system (N40/3) together with bracket		
14	Remove bolts (11) and remove bracket (12) from amplifier for sound system (N40/3)		
15	Install in the reverse order		
16	Code amplifier for sound system (N40/3)	Only when installing new amplifier for sound system (N40/3).	
i⇔ A D	Connect STAR DIAGNOSIS and read out fault memory		AD00.00-P-2000-04A
		STAR DIAGNOSIS diagnosis system	*WH58.30-Z-1048-13A

## Nm Cargo retainers

Number	Designation	Model 164.1/8
BA68.50-P-1001-03F	Bolt, cargo retainers to body Nm	24

## Commercially available tools

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00