

## Front active multicontour seat/ rear multicontour seats/ massage/ pump inoperative and no communication possible via diagnosis

Topic number	LI91.25-P-058219
Version	1
Design group	91.25 Multicontour seat (MCS)
Date	01-23-2014
Validity	Model series 222 valid up to 01.03.2014 (YoM14) / SA code 432 Model series 166 valid up to 01.04.2013 / SA code 399
Reason for change	

### Complaint:

- Function failure of active multicontour seats and all functions associated with them
- No communication with the relevant control units (e.g. they are not listed in the quick test)
- No faults are logged or displayed
- Actuation via XENTRY is not possible

### Cause:

- Writing of data in critical situations (e.g. with low on-board electrical system) is not always successful
- Corrupt data in data flash

### Remedy:

Replace faulty control unit or pump and invoice via special damage code (91606 01)!

<b>Symptoms</b>
Body / Seat / Multicontour seat / Nonfunctional

Parts							
Part number	ES1	ES2	Designation	Quantity	Note	EPC	Other make part
A 222 900 71 03			Left and right front seat control unit	1	Left or right control unit as required	X	
A 222 900 94 03			Left and right rear seat control unit	1	Left or right control unit as required	X	
A 166 900 50 06			Left front seat control unit	1		X	
A 166 900 51 06			Right front seat control unit	1		X	
A 222 900 05 03			Massage control unit	1		X	

A 166 900 18 11		Left front seat control unit	1		X
A 166 900 19 11		Right front seat control unit	1		X
A 166 900 59 09		Left front dynamic seat control unit	1		X
A 166 900 60 09		Right front dynamic seat control unit	1		X
A 166 900 20 11		Front seat massage function control unit	1		X
A 166 900 98 09		Front seat massage function control unit	1		X
A 166 900 89 06		Front multicontour seat control unit	1		X
A 000 800 71 48		Pump	1		X

Work units				
Op. no.	Operation text	Time	Damage code	Note
			91606 01	Active multicontour seat inoperative

WIS-References			
Document number	Title	Note	Allocation
AR91.25-P-1740GQ	Remove/install multicontour seat backrest air cushion	Remove/install control unit / valid for model series 166	Remedy
AR91.25-P-1680LF	Remove/install air cushions of multicontour backrests on driver or front passenger backrest	Remove/install control unit / valid for model series 222	Remedy