

Trunk lid closes too quickly

Topic number	LI88.50-P-057071
Version	1
Design group	88.50 Trunk lid
Date	08-29-2013
Validity	MODEL 222 up to VIN end number 006848 with code 881
Reason for change	

Complaint:

Trunk lid closes too quickly.

Cause:

Closing speed parameter for trunk lid closing function has an incorrect value.

Remedy:

Perform SCN coding of HKS control unit.

(Xentry Diagnostics => Control unit view => KDS control unit => Adaptations => SCN coding)

NOTE:

- The new value of the closing speed parameter is available with add-on 2892 for Xentry Diagnostics DVD 07/13 and/or in the regular way as of Xentry Diagnostics DVD 09/13.

- For W&G processing please use the damage codes listed below!

Symptoms
Body / Door/Flap / Hood/flap / Trunk lid/liftgate / Opens too fast
Body / Door/Flap / Hood/flap / Trunk lid/liftgate / Does not close completely
Body / Door/Flap / Hood/flap / Trunk lid/liftgate / Does not close

Control unit/fault code		
Control unit	Fault code	Fault text
- () { 2 } (PTCM222)	-	-

Work units				
Op. no.	Operation text	Time	Damage code	Note

		75004 IA	
--	--	----------	--