


MODEL 211.0

- 1 Catches
- 2 Housing
- 3 Electrical plug connection

E21 Center high-mounted stop lamp



P82.10-2945-06

☒ ☒	Remove/Install		
1	Remove paneling at trunk lid		<a href="#">AR68.30-P-8150T</a>
2	Slide catches (1) in direction of arrow and remove the casing (2) of the center high-mounted stop lamp (E21) out of the trunk lid until the electrical connector (3) is accessible		
3	Separate electrical plug connection (3)		
4	Unclip and remove center high-mounted stop lamp (E21) out of the trunk lid		
5	Install in the reverse order		