

MODEL 211.0 /2 /6 up to 1.6.08 except CODE (809) Model year 2009








P54.21-2175-07

- 1 Ashtray housing
- 2 Fiber optic coupling (with code (819) CD changer)
- 3 Bracket

Shown on kinematics stowage compartment (7)

- 7 Stowage compartment for
 - kinematics
- 8 Bolts9 Panel
- 10 Electrical connectors
- N72/1 Upper control panel control unit

- 4 Electrical connectors
- 5 Screw
- 6 Safety clip (with code (819) CD changer)
- 7 Stowage compartment for kinematics
- N72/1 Upper control panel control unit



P54.21-2176-06

XX	Remove/install		
(1)	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1	Remove ashtray housing (1) from front center console		AR68.20-P-2400T
2	Unclip fiber optic cable (2) from bracket (3) towards the front	On vehicles with code (819) CD-changer	
3	Unclip electrical connector (4) from bracket (3)	The number of electrical connectors (4) can vary depending on the equipment.	
4	Remove bolts (5)		
5	Pull kinematics stowage compartment (7) or CD changer out of the center console until the electrical connectors (4) and fiber optic coupling (2) are accessible	i Depending on vehicle configuration.	
6	Separate electrical connectors (4)		
7	Remove retaining clamp (6) and disconnect fiber optic cable (2)	On vehicles with code (819) CD-changer	
		To avoid damaging the fiber optic cable, do not kink fiber optic cable, route over sharp edges or bend in radii smaller than 25 mm.	
0	Cover fiber entic cable	On vehicles with code (910) CD changer	AD92 05 D 0005 01 A

9	Take out kinematics stowage compartment (7) or CD changer	Depending on vehicle configuration.
10	Open the flap on the kinematics stowage compartment (7) or on the CD-changer completely	Depending on vehicle configuration.
11	Remove bolts (8) and remove bezel (9) from flap on stowage compartment kinematics (7) or on CD-changer	i Depending on vehicle configuration.
12	Unplug electrical connections (10) and remove upper control panel control unit (N72/1)	
13	Install in the reverse order	