


Model 213, 238








## Modification notes


20.03.2017	Operation step sequence exchanged.	Steps 2 and 3	
------------	------------------------------------	---------------	--

- 1 Floor covering  
2 Door sill



P68.20-4745-11

 	Remove/install		
1	Detach driver's seat and tilt toward rear	 Do not disconnect electrical connectors.	AR91.10-P-1000LW
2	Remove door sill molding (2)	Model 238 Model 213	AR68.30-P-4100CLW AR68.30-P-4100LW
3	Remove paneling below instrument panel on passenger side		AR68.10-P-1502LWE
4	Remove floor covering (1) from front to rear	 Use  assembly wedge in center console area.  <b>Installation:</b> Position floor covering (1) below center console.  Mounting wedge	*110589035900
5	Install in the reverse order		



110 589 03 59 00

Mounting wedge