


Model 205  
 Model 213  
 Model 253  
 Model 293



P68.40-2217-07

## Shown on model 205.0

1	Cover	5	Duct tape
2	Cover	6	Mirror base
3	Foam grommet	7	Open end wrench
4	Electrical connector	A67	Inside rearview mirror

Warning	<b>Risk of injury</b> caused by irritation of the skin, eyes and respiratory system through contact or inhalation of substances contained in the mirror lens.	Wear protective gloves and safety glasses.	AS60.00-Z-0008-01R
Topical note	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
	<b>Remove/install</b>		
1	Remove overhead control panel control unit.	Model 205.0/1/2/3, 213, 253, 293 Model 205.4	AR82.20-P-1000LF AR82.20-P-1000LWR
2	Unclip and remove cover (1).		
3	Unclip and remove cover (2) in direction of arrow.		
4	Push back foam grommet (3).	Model 205, 253, 293 <b>Installation:</b> Completely install foam rubber grommet (3) over electrical connector (4). Otherwise noise may occur.	
5	Disconnect electrical connection (4).	Model 205, 253, 293	
6	Release fabric tape (5).	Model 205, 253, 293	
7	Disconnect electrical connector of mirror taximeter.	Model 213 with code 337 (Taximeter integr.in the rear-view mirror)	
8	Turn inside rearview mirror (A67) at mirror base (6) toward right using an open-end wrench (7) and remove from mirror bracket.		
9	Adjust reading lamps of inside rearview mirror (A67) to steering variant.	When replacing inside rearview mirror (A67).  Model 205, 213, 253 Model 293	AR68.40-P-0001-01A AR68.40-P-0001-01EQ
10	Install in the reverse order.		