


Model 245.2## 1#

**Installation of door sill molding 4-fold**

- 1 Front right and left illuminated door sill molding
- 2 Accessories wiring harness
- 3 Inverter
- 4 Connection couplings to door sill molding
- 6 Wiring harness for illuminated door sill molding
- 7 Rear right and left illuminated door sill molding
- 12 White connector for accessories connection
- 16 2-pin connector housing

- N10 SAM control unit
- W36 Ground (right footwell)



P82.20-2741-06

☒	<b>Remove</b>		
⚠ <b>Danger!</b>	<b>Risk of death</b> caused by contact with parts conducting high voltages.	Do not touch parts which conduct high voltages. Persons who wear electronic implants (e.g. heart pacemakers) must <b>not</b> perform any work on such components.	AS00.00-Z-0020-01A
⚠ <b>Danger!</b>	<b>Risk of explosion</b> caused by oxyhydrogen gas. <b>Risk of poisoning and caustic burns</b> caused by swallowing battery acid. <b>Risk of injury</b> caused by burns to skin and eyes from battery acid or when handling damaged lead-acid batteries	No fire, sparks, open flames or smoking. Wear acid-resistant gloves, clothing and safety glasses. Pour battery acid only into suitable and appropriately marked containers.	AS54.10-Z-0001-01A
1	Connect quiescent current retention unit		*WH58.30-Z-1012-09A
Ⓜ	Disconnect battery ground cable Notes on battery	All models	AH54.10-P-0001-01A
3	Remove battery		
4	Remove right and left, front and rear door sill moldings		
5 👉 AR	Remove passenger seat		AR91.10-P-1000AK
6	Pull off rubber door seal near the A-pillar on both sides at the front		
7	Remove paneling on A-pillar.	<b>i</b> Left and right paneling.	
8 👉 AR	Remove cover beneath instrument panel (left).	<b>i</b> Loosen on left only in order to be able to install the wiring harness.	AR68.10-P-1500AK
9 👉 AR	Remove cover below instrument panel (right).		AR68.10-P-1520AK
10	Remove right front floor covering		
11	Remove fuse box in right front footwell		
12	Remove paneling from left and right B-pillars		
☒	<b>Install</b>		
13	Retrofit wiring harness	<b>i</b> Accessories wiring harness	AZ82.70-P-0001-04BK
14	Connect wiring harness	<b>i</b> Wiring harness for illuminated door sill molding.	AZ82.20-P-0001-02BK

15	Perform function check	<b>i</b> When a door is opened, all door sill moldings are illuminated simultaneously; however, they are automatically switched off again after 5 minutes.	
16	Install remaining parts onto vehicle	Steps 12 to 1.	

#### Commercially available tools

Number	Designation
WH58.30-Z-1012-09A	Quiescent current retention unit

#### Parts ordering notes

Part no.	Designation	Quantity
B6 788 51 52	Accessories wiring harness	1
B6 689 00 05	Illuminated stainless steel door sill rails, front set, 4 parts with black plastic base	as required