


Controls in detail

Locking and unlocking

Important notes on using KEYLESS-GO

- ⑤ Battery check lamp
 - ⑥ **PANIC** Panic button (▷ page 71)
 - ⚠ To prevent possible malfunction, avoid exposing the SmartKey with KEYLESS-GO to high levels of electromagnetic radiation.
 - ⚠ If you cannot lock or unlock the vehicle with the SmartKey with KEYLESS-GO, the batteries in the SmartKey with KEYLESS-GO are discharged, the SmartKey with KEYLESS-GO is malfunctioning or the vehicle battery is drained.
Check the batteries in the SmartKey with KEYLESS-GO and replace them if necessary.
Use the mechanical key to unlock the driver's door and the trunk (sedan only).
Use the mechanical key to lock the vehicle.
Have the vehicle battery and the vehicle battery connections checked at an authorized Mercedes-Benz Center.
If the SmartKey with KEYLESS-GO is malfunctioning, contact Roadside Assistance or an authorized Mercedes-Benz Center.
- You can also use the SmartKey with KEYLESS-GO like a normal SmartKey (▷ page 82).
 - You can combine KEYLESS-GO functions with normal SmartKey functions (e.g. unlocking with KEYLESS-GO and locking with button ).
 - Always carry the SmartKey with KEYLESS-GO with you.
 - Never store the SmartKey with KEYLESS-GO together with:
 - Electronic items such as a cellular phone or another SmartKey with KEYLESS-GO
 - Metallic objects such as coins or metal foil
- Doing so could impair the function of the KEYLESS-GO system.
- To lock or unlock the vehicle, the SmartKey with KEYLESS-GO must be located outside the vehicle within approximately 3 ft (1 m) of a door or the trunk lid/tailgate.
 - In order to start the engine with the SmartKey with KEYLESS-GO:
- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference, and
 2. this device must accept any interference received, including interference that may cause undesired operation.
- Any unauthorized modification to this device could void the user's authority to operate the equipment.
- 1. Canada only:
This device complies with RSS 210 of Industry Canada. Operation is subject to the following two conditions:
 1. This device may not cause interference, and
 2. this device must accept any interference received, including interference that may cause undesired operation of the device.
- Any unauthorized modification to this device could void the user's authority to operate the equipment.