


Document title Disconnect fuel line, stick together

Document number ar4720p551001ew

Engine 156, 157, 271, 272, 273, 274, 276, 278, 642, 651 in model 212


Engine 157, 274, 276, 278, 642, 651 in model 218



P47.25-2100-07

Shown on vehicle with gasoline engine

1 Fuel line



P47.25-2101-07

Shown on vehicle with diesel engine

1 Fuel line

Detach fuel line (1)

i The work area should be cleaned carefully before removal.

- 1 Press lock for fuel line (1) by hand or with a screwdriver in the direction of the arrow and detach fuel line (1) from fitting or fuel line.

Mount fuel line (1)

- 2 Place fuel line (1) on fitting or fuel line.

i Check for correct locking by pulling on the plug coupling.