

Code :	Designation :	Position :
A0	Color code key	32L
A91b1	Electric power steering torque sensor	24L
A91m1	Electric power steering actuator motor	27A
CAN E	Chassis CAN	15K
CAN E	Chassis CAN	20K
CAN E2	Chassis CAN 2	15K
CAN E2	Chassis CAN 2	20K
Code 4U7	Start/stop voltage dip protection	3A
Code B03	ECO start/stop function	3B
Code ME04	Hybrid drive 20 KW VARIANT	3B
Code ME04	Hybrid drive 20 KW VARIANT	10D
F32	Front electrical prefuse box	7L
F32f153	Prefuse 153	5K
F32f157	Prefuse 157	5K
N10/1	Front SAM control unit with fuse and relay module	15L
N68	Electrical power steering control unit	6A
N68	Electrical power steering control unit	17A
N68	Electrical power steering control unit	25A
U12	Valid for left-hand drive vehicles	9D
U13	Valid for right-hand drive vehicles	10D
U240	Valid for all except ECO start/stop function	3A
W2/1	Right front ground point	9F
W2/2	Left front ground point	11F
X30/26	Vehicle floor chassis CAN 2 (CAN E2) potential distributor electrical connector	20L
X30/30	Vehicle floor chassis CAN voltage distributor electrical connector	20L

