








P09.41-2386-09

1 Charge air cooler
2 Bolts
3 Bolts

4 Front crossmember
5 Bolts
6 Nuts

7 Bolt
8 Fan box
9 Supports

 	Remove/install		
	Risk of injury caused by fingers being pinched or crushed when removing, installing or aligning hoods, doors, trunk lids, liftgates or sliding roof	Keep body parts and limbs well clear of moving parts.	AS00.00-Z-0011-01A
	Risk of death caused by vehicle slipping or toppling off the lifting platform.	Align vehicle between columns of vehicle lift and position four support plates at vehicle lift support points specified by vehicle manufacturer.	AS00.00-Z-0010-01A
1	Remove upper radiator crossmember	Model 164 Model 251	AR62.30-P-2300GZ AR62.30-P-2300RT
2	Remove left and right engine intake air ducts		
3	Detach charge air hose upstream of charge air cooler (1)	 Installation: To prevent leaks, check sealing rings for damage and replace if necessary.	AR09.41-P-8621GZB
4	Detach charge air hose downstream of charge air cooler (1)	 Installation: To prevent leaks, check sealing rings for damage and replace if necessary.	AR09.41-P-8625GZB
5	Remove front bumper	Model 164 Model 251	AR88.20-P-2000GZ AR88.20-P-2000RT
6	Remove bolts (2) from top fan shroud (8)		
7	Remove bolts (3) from bottom fan shroud (8)		
8	Remove screw (7)		
9	Unscrew nuts (6) and pull out bolts (5)	 Model 164  Model 251	*BA62.30-P-1004-02D *BA62.30-P-1002-02E
10	Remove front cross member (4)	 Only detach to the extent that the fan shroud (8) can be removed.	
11	Take out fan shroud (8)		
12	Unclip charge air cooler (1) from mounts (9) on radiator		
13	Remove charge air cooler (1)		
14	Install in the reverse order		
15	Risk of accident caused by vehicle starting off by itself when engine is running. Risk of injury caused by contusions and burns during starting procedure or when working near the engine as it is running Carry out engine test run	Secure vehicle to prevent it from moving by itself. Wear closed and snug-fitting work clothes. Do not touch hot or rotating parts.	AS00.00-Z-0005-01A

Nm Front end assembly with front reinforcement

Number	Designation		Model 164.1	Model 164.8
BA62.30-P-1004-02D	Bolt, crossmember to crash box	Nm	18	18

Nm Front end assembly with front reinforcement

Number	Designation		Model 251
BA62.30-P-1002-02E	Bolt, crossmember to crash box	Nm	18