


Test values for gap dimensions

Number	Designation	Model 221
BE60.00-P-1001-01R	Gap dimension	Engine hood to fender Dimension "A" mm 3.5 (±0.5)
		Engine hood to headlamp Dimension"B" mm 3.5 (±0.5)
		Radiator grille/bumper Dimension"C" mm 5 (±1)
		Engine hood to bumper Dimension"P" mm 5 (±1.5)
		Bumper to /headlamps Dimension "Q" mm 3.5 (±0.5)
		Bumper to fender Dimension"R" mm 3.5 (±0.5)
		See picture in AR60.00-P-0700-01S X
BE60.00-P-1002-01R	Gap dimension	Front door to A-pillar Dimension "D" mm 4.5 (±0.5)
		Front door to fender Dimension"E" mm 4 (±0.5)
		Front door to rear door Dimension"F" mm 4.5 (±0.5)
		Trim strip at front door to roof frame Dimension "G" mm 4.5 (±0.5)
		Trim strip at rear door to roof frame Dimension "H" mm 4.5 (±0.5)
		Rear door to side section, bottom Dimension "I" mm 4.5 (±0.5)
		Front door cover to rear door cover Dimension"S" mm 4.5 (±0.5)
See picture in AR60.00-P-0700-01S X		
BE60.00-P-1003-01R	Gap dimension	Trunk lid to rear fender, top Dimension "J" mm 4 (±0.5)
		Trunk lid to taillamp Dimension "K" mm 4 (±0.5)
		Trunk lid to bumper Dimension"L" mm 5.5 (±1.5)
		Rear fender to taillamp Dimension "M" mm 2.5 (±0.5)
		Trunk lid cover to taillamp Dimension "N" mm 4 (±0.5)
See picture in AR60.00-P-0700-01S X		
BE60.00-P-1004-01R	Gap dimension	Fuel filler flap Dimension "O" mm 3.5 (±0.5)
		See picture in AR60.00-P-0700-01S X




129 589 03 21 00


Feeler gauge

i

Adjust hoods, doors and lids as shown in drawing. The gap should not run wedge-shaped or be too narrow at points. Deviations from parallel gap should be max. 0.5 mm over the entire length. If the inside clearance is too large or too small, the movable body parts must be centered accordingly. The reference measurements apply only for repair work on vehicles damaged in accidents.



P60.00-2691-06



P60.00-2692-06