



11/2009 [2009-10-22] SimDAS Ignition ON VIN : WDB2110701A123456 Battery voltage: 12.5 V

Vehicle 211.076 Control unit ---

Main groups

Quick test

Functions performed by more than one control unit


**Control units**

Vehicle-specific data

Entry of order data (repair order number, dealer number, name)

Entry for retrofits and modifications

ESC F1 F3 F6 F11





11/2009 [2009-10-22] SimDAS Ignition ON VIN : WDB2110701A123456 Battery voltage: 12.5 V

Vehicle 211.076 Control unit CGW

Drive

ME-SFI 2.8 - Motor electronics 2.8  
Transmission  
ESM - Electronic selector module  
DTR - Distronic

ESC F1 F3 F6 F11

11/2009 [2009-10-22] SimDAS  Ignition ON VIN : WDB2110701A123456 Battery voltage: 12.5 V

Vehicle 211.076 Control unit ETC

Electronic transmission control ( 722.6 EGS52 )

Control unit version

Fault codes

Event memory

Actual values

Actuations

Initial startup

Control unit adaptations

Initial test / Oil condition check / Oil level check

Warranty or goodwill processing

**Adaptation**

Diagnosis routines

Complete list of guided tests

Full list of fault codes and events

Special function

Control unit log

Control module programming ( Update control module software in compliance with factory specifications. )

Service information

Troubleshooting by means of complaints or symptoms

Development data

ESC F1 F3 F6 F11



11/2009 [2009-10-22]      SimDAS      VIN : WDB2110701A123456      Battery voltage: 12.5 V

Ignition ON

**Vehicle** 211.076      **Control unit** ETC

Adaptation

Definition  
Assignment of hydraulic shift elements  
Important information on adaptation limit values  
Important information on the combination possibilities for adaption end stop values

**Display and reset of adaptation data**

Performing adaptation

ESC      F1      F3      F11

VIN	WDB2110701A123456	Model series/model designation	211.076
Order number		License plate	

Display and reset of adaptation data

Adaptation values of shift 1 - 2:

Adaptation values of shift 2 - 3:

Adaptation values of shift 3 - 4:

Adaptation values of shift 4 - 5:

Adaptation values of shift 5 - 4:

Adaptation values of shift 4 - 3:

Adaptation values of shift 3 - 2:

Adaptation values of shift 2 - 1:

Display all adaptation data.

Resetting of adaptation data

**Filename:** F:\Programme\Das\trees\pkw\getriebe\egs1\menus\MNEGS101.s

**Cell co-ordinate:** 27 , 31