
MODEL 207, 212

Illustrated on model 212


- Trim strips
- Instrument cluster cover
- 2 3 Pin
- Catch hook
- Shackles
- 4 5 6 7 Resetting button
- Bolts
- 8 Instrument panel
- Electrical connector

Instrument cluster A1



P54.30-9905-06

XX	Remove/install		
(1)	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1	Temporarily store basic data of instrument cluster (A1) in STAR DIAGNOSIS	When replacing the instrument cluster (A1).	
		i Installation: Transfer the cached basic data to the new instrument cluster (A1).	
⊯ AD	Connect STAR DIAGNOSIS and read out fault memory		AD00.00-P-2000-04A
2	Position steering wheel rearwards and at the bottom		
3	Switch off ignition and remove transmitter key or KEYLESS-GO start/stop button from electronic ignition lock control unit	i KEYLESS-GO start/stop button only on vehicles with code (889) Keyless-Go.	
4	Remove the left and right trim strip (1) on the bezel of the instrument cluster (2)	On model 212	AR68.10-P-1180EW
5	Unlatch instrument cluster bezel (2) first at the top of the peg (3) then unlatch backwards in the lower area of the catch hooks (4) and remove	Installation: Pay attention to the correct seat of the shackles (5).	
		3	*115589035900
6	Pull reset knob (6) out of the instrument cluster (A1)		
7	Unscrew bolts (7) until the instrument cluster (A1) is loose	The bolts (7) remain on the instrument cluster (A1).	
8	Swing the instrument cluster (A1) at the top out of the dashboard (8) and remove rearwards until the electrical connector (9) is accessible		
9	Unplug electrical connector (9) and remove instrument cluster (A1)		
10	Install in the reverse order		



Long wedge